

FPS CamControl

Volunteer Quick Reference — Xbox Controller

This card covers every default button on your Xbox controller. You only need a few of these to run a normal service. The rest are here so you can find them when you need them.

The basics you'll actually use

Move the camera	Right stick
Zoom in / out	Left stick — UP zooms in, DOWN zooms out
Switch which camera you're controlling	Left stick — flick fully LEFT or RIGHT, then release
Take the new camera live (hard cut)	Right Trigger (RT)
Take the new camera live (smooth transition)	Right Bumper (RB)
Turn lower thirds on / off	D-Pad LEFT or RIGHT (either one toggles it)
Panic button — stop everything	Back / View button (left of the Xbox button)

How camera switching works

There are **two** ideas to keep straight:

Controlled camera — the one your sticks are moving right now. Shown in the top bar of the web panel.

Live camera — what your audience sees on the stream. This is the ATEM Program bus. It *only* changes when you press Right Trigger (cut) or Right Bumper (auto transition).

So you can flick around between cameras as much as you want to line up your next shot — the audience won't see anything change until you pull RT or hit RB.

Speed control (how fast the camera moves)

Move faster	D-Pad UP — cycles up through Slow / Normal / Fast
Move slower	D-Pad DOWN — cycles back down
Slow it WAY down (fine adjustment)	Hold Left Trigger (LT) while moving the right stick — 25% speed
Speed it WAY up (broad sweeps)	Hold Left Stick CLICK (LS) while moving the right stick — 175% speed

The current speed is shown in the bottom of the web panel.

Saved shot positions (presets)

Each camera has four memory slots: A, B, X, Y. You can save the current pan / tilt / zoom into a slot, then recall it instantly later.

Recall preset A / B / X / Y

Press A, B, X, or Y by itself

Save current position to A / B / X / Y

Hold Left Bumper (LB), then press A, B, X, or Y

Presets are per camera — saving slot A on Camera 1 doesn't overwrite slot A on Camera 2.

Complete button reference

Right stick	Pan / tilt the currently controlled camera
Left stick (UP / DOWN)	Zoom in (up) or out (down)
Left stick (flick L/R)	Switch which camera you control
Right Trigger (RT)	Take controlled camera LIVE (hard cut)
Right Bumper (RB)	Take controlled camera LIVE (auto transition)
Left Trigger (LT) hold	Precision mode — 25% speed while held
Left Stick click hold	Sprint mode — 175% speed while held
A / B / X / Y	Recall preset A / B / X / Y on controlled camera
LB + A / B / X / Y	Save current position to preset A / B / X / Y
D-Pad UP / DOWN	Cycle through speed presets (Slow / Normal / Fast)
D-Pad LEFT / RIGHT	Toggle lower thirds on/off
Back / View	EMERGENCY STOP — halts all cameras and turns graphics off

If something seems off

Camera moves on its own when you let go of the stick

Stick drift. Press Back to stop everything, then let the controller sit still for a few seconds before moving again.

Top bar says "Controller: Not Connected"

Wiggle the right stick to wake the Bluetooth connection. If it stays disconnected, ask the technical lead to grant the app Input Monitoring permission.

Lower thirds button doesn't seem to do anything

Confirm someone has the graphic loaded into DSK 1 on the ATEM. The button only toggles the keyer on/off — it doesn't choose the graphic.

Wrong camera goes live when you cut

Check the top bar — the camera with the "Controlled" tag is the one that'll go live. Flick the left stick to change it before pulling RT.

Everything is moving but nothing is on air

Confirm Program (live) on the ATEM is on the input you expect. The web panel's Program tile should match.

Three golden rules

1. The right stick only ever moves *one* camera at a time — the one tagged "Controlled" in the top bar. Always glance up there before you start moving.

2. Nothing the audience sees changes until you pull the Right Trigger or press Right Bumper. Feel free to fly around lining up shots.
3. If you ever feel out of control, press **Back**. Everything stops. Reset, breathe, try again.