## Website User Guide

## **Table of Contents**

Tab Bar	3
Home Screen	4
Flume and Basin Pages	5
Live Views	7
Sign In	8

### Tab bar

- Provides links to other pages on the site
- Shows login status

#### Desktop

(Not signed in)



#### Mobile



(Not signed in)




(Signed in)



#### Home Screen


 Shows current fill level, fill target, and live stream of facilities



### Flume and Basin Pages


- Shows current fill level, fill target, ETA to fill completion, fill target set time, user who created the fill target, and time elapsed
- Allows authorized users to

## Large Wave Flume (Signed in)




# Directional Wave Basin

(Not signed in)




## Flume and Basin Pages cont.



### Live views

Provides all live streams for facilities



## Sign In

• Sign in to gain admin access to facilities

