

XQ+ Slim Bedienungsanleitung

Vielen Dank, dass Sie sich für den Kauf eines Pichler XQ+ Reglers entschieden haben. In der folgenden Anleitung erfahren Sie alles nötige um Ihren neuen ESC korrekt einzustellen und zu betreiben.

Warnhinweise

- PICHLER ist nicht verantwortlich für Ihre Verwendung dieses Produkts oder für Schäden oder Verletzungen, die Sie möglicherweise als Folge seiner Verwendung verursachen oder erleiden
- Ein Elektromotor, der mit dem Batteriepack und ESC verbunden ist, kann unerwartet starten und ernsthafte Gefahren verursachen
- Wir emnfehlen die Luftschraube vor dem Einschalten der Komponenten zu entfernen
- Halten Sie sich an die geltenden Flugbestimmungen
- · Nicht über andere Personen oder Menschenmengen fliegen.

Produktmerkmale


- 1. MOSFET der neuen Generation, geringe Wärmeentwicklung, hohe Strombelastbarkeit und hohe Zuverlässigkeit.
- 2. hochleistungsfähiger 32-Bit-Mikroprozessor, stärkere Rechenleistung und schnellere Laufgeschwindigkeit.
- 3. Super sanftes Anfahren und genaue Linearität der Gassteuerung
- 4. Höhere Antriebseffizienz und mehr Energieeinsparung.
- 5. Mini Größe, geringes Gewicht, gut für Indoor-3D-Flieger.
- 6. Super starke SBEC-Ausgang, kontinuierliche 6V/3A, Spitze 5A Strom
- 7, Mehrere Schutzfunktionen: Start-up, Überhitzung, Unterspannungsabschaltung, Signalverlust, Phasenverlust usw.
- 8. Unterst ü tzt Motoren mit hohen Drehzahlen und ist mit den meisten auf dem Markt erhältlichen Motoren kompatibel.
- 9. Unterst ützung der Programmierung über App oder LCD-Programmkarte, einfachere und bequemere Bedienung. Adapter oder LCD-Programmkarte erforderlich)

Spezifikationen

Тур	Art.Nr.	Dauer/ Kurz(A)	Akku NiXX\Lipo	Gewicht (g)	BEC Ausgang	Größe(mm) L*W*H	Арр
XQ+ 20 Slim	15920	20A/30A	5-12NC/2-4Lipo	11	6V/3A	36*16*10	Ja
XQ+ 30 Slim	15921	30A/40A	5-12NC/2-4Lipo	15	6V/3A	54*18*10	Ja


Der Regler kann durch direktes Löten oder mit hochwertigen Steckern an den Motor angeschlossen werden. Verwenden Sie immer neue Stecker, die sorgfältig an die Kabel gelötet und mit Schrumpfschlauch isoliert werden müssen. Die maximale Länge der Akkupackkabeln darf nicht länger als 15cm sein.

- Löten Sie den Regler an die Motorkahel
- Löten Sie geeignete Steckverbinder an die Akkudrähte.
- · Alle Lötverbinder mit Schrumpfschläuchen isolieren.
- Stecken Sie den "IR"-Stecker in den Gaskanal des Empfängers
- Die roten und schwarzen Drähte des Reglers werden mit den roten und schwarzen Drähten des Akkupacks verbunden



Gasweg einstellen

(Wichtig: Bitte führen Sie die Drosselklappenkalibrierung zum ersten Mal mit ESC durch!!!)







Der Motor piept nun mehrmals (ein Piepton f ü r jede Zelle in Ihrem Akku), gefolgt von einem längeren "Beep-----Beep".

Der Motor aibt zwei kurze Töne von sich, senken Sie den Gaskn üppel in die unterste Position, sobald sobald Sie diese beiden Pientöne hören.



Dies zeigt an, dass das Gas für Ihren ESC jetzt kalibriert und einsatzbereit ist.



Normal startup procedure

Turn on the transmitter move the throttle stick to the bottom position



Connect the battery pack to the ESC and wait for about 2 seconds



When the motor emits " Reen----Reen" means self-test is finished, the ESC is ready to work.



The motor will been several sounds, sounds time presents the amount of hattery cells

Programmieroptionen

Diese Funktion unterst ützt das Umschalten der Motordrehung zur Verlangsamung, wenn das Flugzeug auf dem Roden landet

Die Werkseinstellung ist AUS, der 1Pin-Signaldraht ist zu diesem Zeitpunkt ung ültig. Wenn Sie die Funktion einschalten möchten, programmieren Sie sie mit der Telefon-App oder der LCD-Programmierkarte auf "ON", schließen Sie das 3-polige Signalkabel an den Gaskanal an und stecken Sie das 1-polige Signalkabel in einen beliebigen 2-Stufen-Schalterkanal des Empfängers und schalten Sie dann den 2-Stufen-Schalter des Senders ein. Die RVS-Funktion ist nun eingeschaltet. Sie können die Vorwärts- und Rückwärtsrichtung des Motors durch Umlegen des 2-Stufen-Schalters ändern

Achtung! Diese Funktion ist nur wirksam, wenn der Gashebel unter 50% steht, und sie darf nur verwendet werden, wenn das Flugzeug auf dem Boden landet, da sonst der Regler durchbrennen kann!

- 2. Bremse: OFF/Soft/Mid/Hard
- 3. Timing: Auto/5° /10° /15° /20° /25° /30
- 4. Motor Drehrichtung: CW/CCW
- 5. SR-Funktion: FIN/AUS
- Die Synchrongleichrichtungsfunktion macht den ESC effizienter und energiesparender
- 6. Akku Zellen: Auto/Manuell
- Auto: Wenn "Auto" ausgewählt ist, berechnet der Regler automatisch die Anzahl der Lipo-Zellen gemäß 3.8V/Zelle
- 7. Niederspannungsabschaltung: OFF/2.3V/2.5V/3.0V/3.2V/3.4V/3.6V
- Beispiel: Bei Verwendung von 4 Lithiumbatterien und der Einstellung von 3,0 V als Grenzwert für die Unterspannung beträgt der Schwellenwert für den Unterspannungsschutz: 4*3,0 = 12,0 V
- 8. Niederspannungsabschaltung Typ: Leistung reduzieren/Leistung abschalten
- Reduzierte Leistung: Wenn Spannung auf den Schwellenwert für den Unterspannungsschutz fällt, reduziert der Regler die Leistung auf 70%. Leistung abschalten: Wenn Spannung auf den Schwellenwert für den Unterspannungsschutz abfällt, schaltet der ESC die Leistung sofort ab. 9. BEC: 6.0V/7.4V/8.4V
- BEC der 25A, 35A, 45A ESCs ist 5V, 6V, 7.4V, die HV Varianten haben kein eingebautes BEC.
- 10. Beschleunigung: Normal/Weich
- Bitte stellen Sie sicher, dass Sie die "weiche" Beschleunigung wählen, wenn Sie EDF-Jet-Flugzeuge verwenden
- 11. Anfahrleistung: Niedrig/Mittel/Hoch

SCHUTZFUNKTION

FEHI FRREHERUNG

1. Startschutz: Wenn der Motor nicht innerhalb von 2 Sekunden nach dem Drücken des Gashebels normal startet. wird der ESC abgeschaltet, und Sie m ü ssen die Gaskalibrierung erneut vornehmen, dann kann der ESC neu

Mögliche Gründe: Verbindungsabbruchoder schlechte Verbindung zwischen ESC und Motor, der Propeller oder Motor ist durch andere Gegenstände blockiert, das Getriebe ist beschädigt usw.)

- 2. Überhitzungsschutz: Wenn die Temperatur des ESC über 110°C liegt, reduziert der ESC automatisch die Leistung Leistung zum Schutz, aber schaltet die Leistung nicht vollständig ab.
- 3. Schutz vor Gas-signalverlust: Der ESC reduziert die Ausgangsleistung, wenn das Gassignal für 1 Sekunde ausfällt, und schaltet den Ausgang zum Motor ab, wenn das Gaspedalsignal länger als 2 Sekunden ausfällt. Wenn das Gassignal während der Abschaltung wiederkehrt, nimmt der Regler sofort die Gassteuerung wieder auf. Auf diese Weise sch ü tzt der Regler nicht, wenn der Signalverlust weniger als 2 Sekunden beträgt, sondern nur, wenn der Signalverlust ü ber 2 Sekunden oder länger ist. Außerdem reduziert der ESC die Ausgangsleistung schrittweise, anstatt sie sofort abzuschalten, so dass Sieeine gewisse Zeit haben, um das Flugzeug zu retten.
- 4. Überlastschutz: Der ESC schaltet die Stromversorgung ab oder startet automatisch neu, wenn die Last plötzlich stark ansteigt, möglich Ursache ist ein blockierter Motor

Fehler	möglicher Grund	Behebung
Nach dem Einschalten	mognetici didila	benesang
ertönen die LiPo Töne.	ESC setzt den Gasweg nicht.	Gasweg neu einstellen.
aber der Motor läuft nicht	LSC SCIECUCII Gusweg mene	dusweg neu einstehen.
Nach dem einschalten	1. ESC und Akku haben eine schlechte Verb.	1.Verbinder reinigen und auf richtige Polarität
kommt kein Ton,	2. Schlechte Lötstellen	achten
und der Motor läuft	3. Akku leer bzw. niedrige Spannung	2. Löten Sie die Kabel erneut
nicht.	4. Beschädigtes ESC.	3. Zellenspannung d. Akkus pr ü fen.
		4.Change ESC.
Der Motor funktioniert		
nicht und kein hörbarer	1. Schlechte Verbindung zw. Akku und ESC	Pr ü fen Sie alle Verbindungen
Ton ertönt nach dem	2. Kein Strom	
Anschließen der	3. Schlechte Lötstellen	
Batterie. Die Servos	4. Verpolt	
funktionieren auch nicht.		
Motor funktioniert,	1. Schlechte / lockere Verbindung	1. Alle Verbindungen pr ü fen.
Servos aber nicht.	zwischen ESC und Motor	2. Motor wechseln.
	2. Durchgebrannte Motorspulen	3. Verbindungen neu löten.
	3. Die Akkuspannung ü bersteigt die	4. Akku pr ü fen.
	Akzeptable Reichweite.	5. Gasweg neu einlernen.
	4. Gaskn ü ppel nicht in niedrigsten Position	
	5. ESC-Gaskalibrierung wurde n. eingerichte	t
Wenn der ESC an ist,	Gashebel ist nicht auf 0.	Gashebel auf 0 stellen.
der Motor nicht		
Arbeit und ein Alarmton		
(dauernd piepen)		
erklingt.		
Motor läuft in die	Polarität der Kabel vertauscht.	Wechseln Sie die Drehrichtung des Motor über die
falsche Richtung.	r olaritat del riabel vertadoenti	Einstellungen oder tauschen Sie 2 der 3 Kabel zum
raiscrie nicitarig.		Motor.
		motor.
Motor stoppt im Flug	Gas-Signal verloren	Überpr ü fen Sie den ordnungsgemäßen Betrieb
		der Funkausr ü stung.
		,

Pichler Modellbau GmbH Lauterbachstrasse 19, 84307 Eggenfelden, DE Tel: +49 8721 - 50 82 66 0 | email: mail@pichler.de | www.pichler.de

XO+ Slim manual

Thank you for purchasing ZTW Mantis Slim G2 Brushless Electronic Speed Controller (ESC). Please read the safety information contained in this manual carefully before using this product. ZTW Model have no control over the use, installation, application, or maintenance of these products, thus no liability shall be assumed nor accepted for any damages, losses or costs resulting from the use of this item.

Important warnings

- · Pichler is not responsible for your use of this product, or any damage or injuries you may cause or sustain as a result of its usage
- Always place safety as priority when you use the product
- · An electric motor that is connected in combination with a battery and/or ESC may start unexpectedly and cause serious damage and so should always be used with care and respect.
- We recommend you always remove the propeller when working on a model with the power source connected.
- · Follow and observe all local laws and by-laws relating to model flying when flying RC planes.
- . Never fly over others or near crowds.

Key features

- 1. Adopting new generation craft on the MOSFET, low heat generation, withstand large current instantly, and high reliability.
- 2. Adopting high performance 32 bit microprocessor, stronger computing ability and faster running speed.
- 3. Super smooth start-up and accurate throttle linearity.
- 4. Higher driving efficiency and more energy-saving.
- 5 Mini size light weight good for indoor 3D flying
- 6. Super strong SBEC output, continuous 6V/3A, peak 5A current.
- 7. Multiple protections: start-up, over-heat, low-voltage cutoff, signal loss, phase loss etc.
- 8 Support high RPM motors, and compatible with most motors in the market
- 9. Support programming via Phone App or LCD program card, easier and more convenient operation.


Specification

Туре	PN#Model	Cont./Burst Current(A)	Battery cell NiXX\Lipo	Weight (g)	BEC Output	Size(mm) L*W*H	User Program
XQ+ 20A Slim	15920	20A/30A	5-12NC/2-4Lipo	11	6V/3A	36*16*10	Yes
XQ+ 30A Slim	15921	30A/40A	5-12NC/2-4Lipo	15	6V/3A	54*18*10	Yes

Wires Connection

The speed controller can be connected to the motor by soldering directly or with high quality connectors. Always use new connectors, which should be soldered carefully to the cables and insulated with heat shrink tube. The maximum length of the hattery nack wires shall be within 6 inches

- · Solder controller to the motor wires
- Solder appropriate connectors to the hattery wires
- · Insulate all solder connectors with heat shrink tubes.
- . Plug the "JR" connector into the receiver throttle channel
- Controller Red and Black wires connects to battery pack Red and Black wires respectively.



Throttle calibration

(Important: Please make the throttle calibration for the first time using ESC!!!)

Turn on the transmitter, move the throttle stick to the top position.







The motor will beep several sounds, sounds time presents the amount of battery cells.

When the motor emits " Beep----Beep."

means the ESC is ready to work.



The motor will beep for twice, then move the throttle stick to the bottom position in 3 seconds.



Normal startup procedure


Turn on the transmitter, move the throttle stick to the bottom position



Connect the battery pack to the ESC and wait for about 2 seconds



When the motor emits "Beep----Beep", means self-test is finished, the ESC is ready to work.



Programming items(the option written in bold font is the default setting)

1. SMR Function: OFF/ON

This function supports switching the motor rotation to decelerate when the airplane landing to the ground. The factory default is OFF, the 1Pin signal wire is completely invalid at this time. If you need to turn it on, using Phone App or transmitter to program it "ON", plug the 3Pin signal wire into the throttle channel, and plug the 1Pin signal wire into any 2-stage switch channel of the receiver, then turn on the transmitter 2-stage switch. The SMR function is turned on now, you can change the forward and reverse directions of the motor by flipping the 2-stage switch of the transmitter.

- Warning: This function can only be effective when the throttle is below 50%, and it is only allowed to be used when the airplane is landing on the ground, otherwise it may cause the ESC to burn!
- 2 Brake Type: OFF/Soft/Mid/Hard
- 3. Timing: Auto/Low/Mid/High(5° /15° /25°)
- 4. Motor Rotation: CW/CCW
- 5 SR function: ON/OFF

The synchronous rectification function makes ESC with higher driving efficiency and more energy-saving.

- 6. Battery cells: Auto/2S/3S/4S
- 7 Low Voltage Cutoff Threshold: OFF/NIMH50%/NIMH60%/3 0V/3 2V/3 4V/3 6V

For example: using 3 lithium batteries and setting 3.0V as the low voltage cutoff value, then the low voltage protection threshold is: 3*3.0 = 9.0V

8. Low Voltage Cutoff Type: Reduce Power/Cut Off Power

Reduced power: When the voltage drops to the set low-voltage protection threshold, the ESC will reduce power to 70%. Cut Off power: When the voltage drops to the set low-voltage protection threshold, the ESC will cut off the power immediately

- 9 RFC 6V/3A
- 10 Acceleration: Normal/Soft

Protection function

Trouble

- 1. Start-up protection: If the motor fails to start normally within 2 seconds after pushing the throttle to start, the ESC will cut off the output power, and you need to make the throttle calibration again, then ESC can be restarted. Possible reasons: disconnection or poor connection between ESC and motor, the propeller or motor is blocked by other objects, the gearbox
- 2. Over-heat protection: When the temperature of the ESC is over about 110°C, the ESC will automatically reduce the output power for protection, but will not fully shut down the power, reduce it to 70% of the full power at most to ensure the motor has enough power to avoid crashes.
- 3. Throttle signal loss protection. The ESC will reduce the output power if throttle signal is lost for 1 second, will cut off output to the motor if the throttle signal is lost over 2 seconds. If the throttle signal recovers during power down, the ESC will immediately resume throttle control. In this way, the ESC will not protect when the signal loss less than 2 seconds, only when the signal lost is over 2 seconds or longer time. And the ESC will reduce the output power gradually instead of cutting off it immediately, so the player has certain amount of time to save the plane, taking into account safety and practicality.
- 4. Over load protection: The ESC will cut off power or restart automatically when the load increased a lot suddenly, possible reason is the motor blocked

Action

Possible Reason

Trouble shooting

After powering up, ESC ESC doesn't set throttle range Set throttle range again emits the sound of hatter cells but motor can't run After powering up, motor 1.Bad connection between ESC and battery. 1 Clean the connectors or replace them, check doesn't run and doesn't 2.Bad soldering cause bad contact. the connection polarity emit any sound 3.Low voltage of the battery. 2.Solder the wires again. 3.Check battery pack, use full-charged battery. 4. Quality problem of ESC. 4.Change ESC. Motor does n't work and 1. Poor/loose Connection between battery Check all the connections make sure you are doing no audible tone emitted Pack and ESC it riaht. after connecting the 2. No power 3 Poor soldered connections battery. Servos are not 4. Wrong battery cable polarity working either. 5. ESC throttle cable connected to receiver in the reverse polarity 1. Poor / loose connection between ESC 1. Check all the connections make sure you are Motor does not work but servos do and motor doing it right. 2. Burnt motor coils 2. Change a new motor 3. The battery pack voltage exceeds the 3. Solder the wires again. 4. Check the battery pack, use full-charged battery. acceptable range. 4. Throttle stick is not at the lowest position 5. Set throttle range again. 5. The ESC throttle calibration has not set up When the ESC is powered The throttle stick is not in the bottom Move the throttle stick to the bottom position. on, the motor does not position after power on. work and an alarm sound (continuously beeping) will sound. Motor runs in reverse Wrong cables polarity between the ESC Swap any two of the three cable connections between rotation and the motor the ESC and the Motor or access the Motor Rotation function via the ESC programming mode and change the pre-set parameters. Motor stops running in Lost throttle signal Check proper operation of the radio equipment. Check the placement of the ESC and the Receiver and flight. check the route of the receiver's aerial and ESC