

Ruijie RG-EW1200 User Guide Router Specifications

1.1 Front Panel

The router's LEDs are located on the front panel.

1.2 Rear Panel

Accessing the Router

Step 1: Connect your device with Router Connect your end device (Laptop/PC) to router's network via Wi-Fi or LAN port. For Wi-Fi Connect the Wi-Fi of your device with the Router's Wi-Fi. For Ethernet Connect the ethernet port of your device with any LAN port of the router.

Step 2: Get the IP Address Open the Ruijie web interface through the IP address 192.168.110.1 or check on backside of your router. You can also get the IP address by running ipconfig command in CMD and look for default gateway. By default, there is no username or password and can be set up initially.

Step 3: Do Initial Settings to configure Router This interface appears after page loading is successful. Click on configure Update SSID, Wi-Fi password and time settings and click on Next. When your Wi-Fi settings are successfully upgraded, it will disconnect Wi-Fi. Enter the password mentioned earlier and reconnect When the W-Fi is reconnected, some basic router details related to Internet and Wi-Fi will appear. Click on Next and the following web interface is displayed

Changing Login Password

For changing router login password; Go to profile option on the top right of web interface and select change password. OR Click on More >> Select System >> Click on Login. Enter Old password (same as Wi-Fi password) and enter new password. Click Save Enter the updated login password on this page to login

Check Connected Devices with the Router

To check connected devices Go to More Option >> Click on LAN >> Open DHCP Clients All the connected devices with their MAC Addresses wil appear

WAN Interface (PPPoE/DHCP/Static)

Click on WAN >> Click Internet. In drop down menu, Select Internet type DHCP/PPPoE/Static IP according to your connection with ISP. By default settings are DHCP For PPPoE dialing in router and main ONT acting as a bridge, Get PPPoE credentials from your ISP

Configuring Router as an Access Point/Signal Booster

Click on More Option >> Select Work Mode >> Select Access Point >> Click on Check Confirm SSID and password. Click on Save. Your router is now configured as an Access Point. You can also configure it as Wireless Extender/Repeater by selecting the option Basic Wi-F Configurations

To check Wi-Fi configurations

Go to More Option >> Click on WLAN >> Select Wi-Fi >> Set password and security parameter. Click on Radio Frequency to select region and channel for 2.4G and 5G. After successful login, following page appears. Provides current status information about the router

Wireless MAC Filtering

To block/allow any device to connect to Wi-Fi MAC Filtering is used. Go to More Option >> Click on WLAN >> Select Blocklist/Allow list. Add MAC address of device on which function is to be performed. Click on Add. MAC will be added to the list This Pop-up appears after clicking on Add.