

Huawei Edge ONT K562e User Guide Table of Contents 1. Edge ONT Specifications 1.1 Front Panel 1.2 Rear Panel 2. Accessing Edge ONT 3. Configuring Edge ONT as an Access Point 4. Get Device Information 5. Check Connected Devices 6. Logging in to an Edge ONT configured as an Access Point 7. Basic Wi-Fi Configurations 8. Configure as a Wi-Fi Repeater 9. Connect multiple Access Points 10. Control access to your Edge ONT Device 11. Check Connectivity and Device Logs

Huawei Edge ONT K562e User Guide 1. Edge ONT Specification

1.1 Front Panel

1.2 Rear panel

Accessing Edge ONT Connect ethernet wire with your laptop along with K562e access point's LAN port. After that, visit browser and type <http://192.168.101.1/> for configuring that accesspoint. Moreover, web page automatically appears having this URL: K562e. Click on the start button on WEB page to configure router.

Configuring Edge ONT as an Access Point Once the Start button is pressed, the Interface shows two options. Either you can configure ONT via ethernet using WAN port of ONT or configure it wirelessly. Click on WIFI Uplink button to configure our access point wirelessly

Wi-Fi uplink button will browse for some moment and try to look for all available SSIDs from which you can configure this K562e access point. It will take some time just like this

After some time, it will show all SSIDs in your network. Click on SSID with which you want to configure this K562e access point. Clicking the SSID will ask you to enter User name and Password For AX-5G as mentioned below you have to enter the credentials of that Wi-Fi to configure the access point After adding credentials click on Next, new WEB page will appear to set login password of K562e access point. After setting login password, click on Next and device will start configuring taking a few seconds When configurations get completed, following message will appear on WEB page Note: Internet light gets blue steady ON after configurations. Wi-Fi name and password will be same as per Wi-Fi with which you had configured the K562e access point. Moreover, If Wi-Fi name is not same as of AX-5G (used here as an example) then it means K562e had not configured properly and needs to be configured it again 4. Get Device Information Login into ONT using IP: 192.168.18.1 and get all the information about our K562e access point. Click System Information > Home Network and then you can get all the details including serial number, model, version and online duration of our K562e access point Check Connected Devices Go to home tab in ONT and click on Wi-Fi devices on main page. View the Connected devices, Connection Duration, MAC and IP address of our K562e access point Click on details to get user device detailed info just like mentioned below Logging in to an Edge ONT configured as an Access Point Password for logging access point is as same as default

password written on the backside of ONT. After logging in you will get the home page of K562e router Basic Wi-Fi Configurations Click on My Wi-Fi tab to get all Wi-Fi setting from where you can change Wi-Fi name, password and encryption mode of your access point's Wi-Fi settings. You can also change Wi-Fi power mode of your access point For Advanced Wireless Settings, Click on WLAN Information > WLAN Advanced Configurations For Wireless Devices Information, Go to System Info > WLAN Information For checking additional features, Go to WLAN Information > Smart Network Connection Configure as a Wi-Fi Repeater Go to WLAN Information > Smart Network Connection. In case you want to change configurations of your access point and want to configure the same access point with other ONT's Wi-Fi. You can simply click modify configurations tab and can change the configurations of your K562e access point Connect multiple Access Points To connect multiple access points, Go to WLAN Information > Multi-AP Role Setting. By using this setting your Router will connect to the available AP automatically Control access of your Device Go to Security Configuration > Device Access Control. In this tab you can enable or disable how and which devices can access your K562e Access Point. As for below case, the Wi-Fi devices are allowed to access Web pages Check Connectivity and Device Logs View any form of logs from any connected device with your access point 'Maintenance Diagnosis'. Also use the maintenance function to check LAN or Internet connectivity