

Huawei GPON (Single band ONT) User Manual (HG8247 HG8247T HG8247H)

1. Introduction Huawei HG8247 is an Optical Network Terminal (ONT) that operates on GPON technology. This device includes following features: 2 – Telephone Ports 4 – Gigabit-Ethernet Ports 1 – RF-Video Port 1 - USB Port 2. ONT Specifications It includes Interfaces and LED indicators, shown below: Interfaces 3. Web Configuration Guide It shows how to access ONT within premises. 3.1 Login Credentials Access ONT web interface by entering the following IP address on browser. 192.168.100.1 This page will appear Login into ONT by entering the following credentials: root admin 4. Status After accessing ONT, front page will show various tabs including: Status, WAN, LAN, WLAN, Security, Forward Rules etc. 4.1 Device Information After clicking 'Status Tab' then click on 'Device information'. It shows following details 4.2 User Defined Information Under this tab, you can check the number of devices connected to your Wi-Fi by clicking user defined information icon under status tab. 4.2.1 Connected device Click on 'User Device Information'. This page will appear Devices with status 'online' will be active at that time. Devices with status 'offline' will not be connected at that time but were active during last 3 days. 5. Configuring WLAN For setting Wireless settings. Step 1: Go to WLAN> click on WLAN basic configuration > set the SSID (Network name). Enable the SSID by checking the box Set the Authentication mode to WPA/WPA2 PreSharedKey and Encryption mode to AES. Set the Wi-Fi security key (Password). It should be 8 to 63 characters After setting SSID (network name) and password, click on apply button at the end of setting to apply and save the changes Step 2: Go to WLAN> click on WLAN Advanced configuration Change the regulatory domain to "Pakistan", channel to "Automatic" setting and channel width to "20MHz". Click on apply button to save the changes 6. Security Under this tab, you can allow and block devices by clicking on MAC Filtering tab. 6.2 Blacklisting Click on security > Go to Mac Filter configuration > Enable Mac Filter > Select Filter Mode (If you want to block particular devices then select 'Blacklist') > Click on New > Under Device name option > Write Mac Address of the device (to be blocked) > Click on Apply option. Note: This step block access of particular device to your Network 6.3 Whitelisting Click on security > Go to Mac Filter configuration > Enable Mac Filter > Select Filter Mode (If you want to access particular devices then select 'Whitelist') > Click on New > Under Device name option > Write Mac Address of the devices > Click on Apply option. Note: This step allow only selected devices to have internet access to your Network 7. Forward Rules Under this option, you can directly allow your device to access internet via port forwarding. Note: This is only valid for customers with E-view/Optimus packages. On clicking forward rules > Go to port mapping configuration > Click on New > Always select type: user-defined > WAN name must be Internet > Add IP in Internal Host of particular device which is supposed to be port forwarded (Note: check IP of device by 'ipconfig' command in command prompt) > Keep External Source IP Address to be empty > lastly click on ADD option and apply. Note: Allowed ports will be 7777, 8888, 8080, 8000 8. Precautionary Measures 1. Never remove the power cable from the ONT as this can

damage the ONT. 2. Only connect the ONT with the UPS provided by NAYATEL as other UPS can damage the ONT. 3. Do not cover the ONT as this blocks the ventilation for the ONT circuitry. 4. Never reset the ONT by pressing the Reset button as this will remove all configurations of ONT. 5. Do not change the ONT location as it may damage the optical fiber cable. Please contact NAYATEL Support in this regard