

Naya Box (Android TV Box) User Manual Table of Contents Home Pag App Google Play Stor  
Notificatio Setting Network and Interne Account and Sign I Apps Setting Device Preference Date  
and Tim Languag Keyboar App key Definitio Display and Soun Storag Home Screen Setting  
Customize channel Reorder app Google Assistan Chromecas Remote and Accessorie  
Pairing/Unpairing a Remot File Manage Conclusion Naya Box (Android TV Box) User Manual

Home Page Navigate the Home screen menu using the arrow keys on the remote control. Press the OK button to select and open the desired section Apps The Apps screen displays bundled applications. Use the arrow keys on the remote to navigate and press the OK button to open the desired app options. From these options, you can add the app to favorites, move it, or view app information. Additionally, you can download and install more supported apps from the Google Play Store. +92 (51) 111 11 44 4 Google Play Store When you open the Google Play Store, it will display a selection of apps available for download to your Naya Box Notifications The Notification tab displays notifications related to your apps, allowing you to take direct action as needed. It also shows Google sync and account-related notifications Settings Navigate to the Naya Box Home screen. Click on the Settings tab to access network options and various settings that can help enhance the features of your Naya Box Network and Internet Check the status of the Ethernet or Wi-Fi section in Network and Internet. If it shows as connected, the network connection is 'OK'. For optimal performance, it is recommended to connect using an Ethernet cable or a 5GHz Wi-Fi network Accounts and Sign-in In the Settings tab, navigate to 'Accounts & Sign-in'. To connect with your Google account, click on the 'Add Account' option. Apps Settings In the Settings tab, navigate to 'Accounts & Sign-in'. To connect with your Google account, click on the 'Add Account' option Device Preferences Device Preferences assist with various general settings of the box. They help you manage the appearance of the Home screen, as well as the language, date, and time settings of the device Date and Time Time synchronization (date and time adjustment) is crucial for connecting your box to the internet. Incorrect settings can result in internet connectivity errors in apps. You can adjust the date and time by navigating to the 'Date and Time' tab in the settings. In the Date and Time settings, it is recommended to select 'Automatic' and use the network-provided time. Choosing the 24-hour time format is optional and can be set according to your preference Language From the Language tab, you can select the language for the box. Choose any language in which you prefer to use your device Keyboard In the Keyboard section, you can easily change your keyboard style and configure Gboard settings App Key Definition The App Key Definition feature allows you to set up shortcut keys to directly open specific apps using buttons on the remote control. Display and Sound In display and sound section you can check the display settings and set the resolution of the TV. You can also setup the sound from advanced settings. You can zoom in and out the screen from these settings Storage For installation, navigate to the Storage tab. In the Storage menu, you can view the internal shared storage. Home Screen Settings In the Device Preferences tab, navigate to the Home Screen option. This menu allows you to customize the appearance of your home screen

to make it more attractive. By default, apps are added to the home screen, but you can change these settings from this menu. Customize channels In the Customize Channels section, you can select which apps will display their data on the home screen. For example, if you select Netflix, Prime Video, and YouTube, content related to these apps will be shown on the home screen.

Additionally, one promotional channel is included by default Reorder apps The Reorder Apps feature allows you to arrange the apps on the home screen. You can easily move your favorite apps to the top of the list. Use the arrow keys on the remote for navigation and press the OK button to save your settings Google Assistant The Reorder Apps feature allows you to organize the apps on your home screen. Easily move your favorite apps to the top of the list. Use the arrow keys on the remote to navigate and press the OK button to save your settings.

Chromecast The Naya Box has a built-in Chromecast feature, allowing you to easily connect your devices and control media casting on this device. Remote and Accessories The Remote and Accessories feature allows you to connect your remote or Bluetooth devices to the TV. You can easily connect speakers and mobile phones via Bluetooth.

Pairing/Unpairing a Remote To see the paired remote, navigate to Settings à Remote & Accessories & see the “connected” device To unpair the remote/device, simply click on the remote/device name and click on “Unpair”.

The device will be unpaired. If the remote gets unpaired due to some reason, press the Home ( ) & back ( ) buttons simultaneously for 10 seconds, until this screen appears. The distance between remote and box should not be more than 20 cm. Follow the same procedure to pair a new remote File Manager Navigate back to the Apps section and open the File Manager to view the internal storage and its contents. The File Manager organizes your files into separate folders such as Main Storage, Downloads, and Images. Screenshots are saved in the Images folder.

Conclusion This manual helps you, as a customer, to complete the basic settings of your ATV Box. If you encounter any issues, please contact our helpline at 1441 for further assistance