

Dual-Band TP-LINK Router User Guide Router Specifications TP-LINK Router Front Panel The router's LEDs are located on the front panel 1.2 Rear Panel Back view of the router contains following parts. Web User Interface (Accessing Router) Step 1: Connect device Connect your end device (Laptop/PC) to router's network via Wi-Fi or LAN port. For Wi-Fi: For Ethernet: Connect the Wi-Fi of your device with the TP-Link Wi-Fi. Wi-Fi password is given on the backside of your router. Connect the ethernet port of your device with any LAN port of the router. Step 2: Get the IP Address Open the TP-Link web interface through the IP address listed on the label on the bottom of your router. You can also get the IP address by running ipconfig command in CMD and look for default gateway. OR Open the TP-Link web interface through the website <http://tplinkwifi.net/> By default, there is no username or password and can be set up initially.

Step 3: Login Credentials Enter Login credentials (Username/Password) taken from the back side of your router If router is not accessed with the password mentioned on the backside of router, try 'admin'. If no password is accepted, then try resetting the router as mentioned in '1.2'. After successful login, following page appears. Provides current status information about the router

Another interface of TP-LINK router can be like this: Configuring TP-LINK Router as an Access Point/signal booster Step 1 In Quick Setup >> Select the Dynamic IP option >> Select Next.

Step 2 Select the option 1: No, I do not need to clone MAC address

Step 3 Click on the check box to enable/disable the wireless band

Step 4 Set Wi-Fi name, password, region and security feature for both 2.4G and 5G band

Step 5 Wait until the status is updated to success and then press finish

Another interface of TP-Link router configured as an Access Point is given as: Go to Advanced >> Operation Mode >> In Switch Mode, Select Access Point. Click on save button to save the changes. Router will reboot after the changing the operation mode. Following is the step-by-step process Check Connected Devices with Router Click on DHCP >> Go to DHCP Client List. All the connected devices with their MAC address will appear Wireless MAC Filtering To blacklist or whitelist a device for wireless connection, The MAC filtering option is used. Step 1 Go to Wireless 2.4GHz >> Click on Wireless MAC Filtering option. Click on Deny to restrict access to the devices. Click on Add New Step 2 Enter the device MAC with description to be filtered Wi-Fi 2.4 and 5G Basic Configurations 2.4G Go to Wireless 2.4GHz >> Basic Settings. Update standard parameters and save For other Interface, Go to Wireless >> Settings, update parameters and click Save 5G Same steps as 2.4. Parameters are updated according to 5G band Change Login Password Go to System Tools >> Password. Enter Old and New Password. Click on Save. Password will be updated