Model: BX-150 Wheel Loader

Service Manual - Evaluation Edition (fictional)

Model: BX-150 Wheel Loader

Section 1: Hydraulic System

Fault codes

H101 Hydraulic oil temperature too high

H102 Lift circuit pressure low

H103 Steering pilot pressure sensor out of range

Section 2: Hydraulic System

Troubleshooting H101: Hydraulic oil temperature too high

1. Park the machine and idle for 5 minutes.
2. Check the oil level in the sight glass.
3. Clean the oil cooler fins.

Section 3: Hydraulic System

Troubleshooting H102: Lift circuit pressure low

1. Check the lift relief valve setting.
2. Inspect the lift cylinder seals for leakage.
3. Replace the main pump if pressure stays low.

Section 4: Hydraulic System

Troubleshooting H103: Steering pilot pressure sensor out of range

1. Inspect the sensor connector for corrosion.
2. Measure sensor supply voltage.
3. Replace the pilot pressure sensor.

Model: BX-150 Wheel Loader

Section 5: Engine

Fault codes

E201 Coolant temperature high

E202 Engine oil pressure low

E203 Fuel rail pressure below target

Section 6: Engine

Troubleshooting E201: Coolant temperature high

1. Stop the engine and let it cool.
2. Check the coolant level.
3. Clean the radiator core and test the thermostat.

Section 7: Engine

Troubleshooting E202: Engine oil pressure low

1. Check the oil level and viscosity.
2. Replace the oil filter.
3. Test the oil pressure sender.

Section 8: Engine

Troubleshooting E203: Fuel rail pressure below target

1. Replace the fuel filter.
2. Check the supply pump inlet for air leaks.
3. Test the rail pressure sensor.

Model: BX-150 Wheel Loader

Section 9: Transmission

Fault codes

T301 Transmission oil temperature high

T302 Clutch pack slip detected

Section 10: Transmission

Troubleshooting T301: Transmission oil temperature high

1. Reduce load and let the machine idle.
2. Check the transmission oil level.
3. Inspect the transmission cooler lines.

Section 11: Transmission

Troubleshooting T302: Clutch pack slip detected

1. Check clutch pressure at the test port.
2. Inspect the clutch discs for wear.
3. Replace the clutch pack if worn.

Model: BX-150 Wheel Loader

Section 12: Electrical System

Fault codes

A401 Battery voltage low

A402 Alternator charging fault

Section 13: Electrical System

Troubleshooting A401: Battery voltage low

1. Measure battery voltage at rest.
2. Clean the terminals.
3. Test the alternator output.

Section 14: Electrical System

Troubleshooting A402: Alternator charging fault

1. Check the alternator belt tension.
2. Inspect the charging wire.
3. Replace the alternator.