

How to install the SBP Wall tool in Revit

For: IC Singapore BIM team · **Revit:** 2026 · **Time:** about 15 minutes, once **Questions:** Akash

The SBP Wall tool places a Secant Bored Pile wall (HARD / SOFT piles) along any line you draw in Revit, including straight lines, arcs, circles and joined lines, and counts the piles.

Before you start: you need

1. **Revit 2026**
 2. A **GitHub account** (free): <https://github.com/signup>. Send your username to Akash.
 3. The **invite email** from GitHub ("...invited you to collaborate on SBP-pyRevit"). Click **Accept invitation**.
-

Step 1: Install pyRevit (skip if you already have it)

1. **Close Revit.**
2. Download the latest pyRevit installer: <https://github.com/pyrevitlabs/pyRevit/releases> (under **Assets**, pick the file ending in `.exe`, e.g. `pyRevit_x.x.x_signed.exe`).
3. Run it and keep the default options.
4. Open Revit 2026. You should see a **pyRevit** tab.

Step 2: Install GitHub Desktop

1. Download it from <https://desktop.github.com> and install it.
2. Open it and **sign in** with your GitHub account.

Step 3: Download the SBP tool

1. In GitHub Desktop: **File** → **Clone repository**.
2. Choose the **GitHub.com** tab, then select **SBP-pyRevit** from the list. (If it isn't listed, you haven't accepted the invite yet. Check your email.)
3. **Local path:** `C:\pyRevit-Ext\SBP-pyRevit`
4. Click **Clone**.

Step 4: Connect it to Revit

1. Open Revit 2026 → **pyRevit** tab → **Settings** (click the pyRevit logo button).
2. Find **Custom Extension Directories** → **Add folder** → select `C:\pyRevit-Ext\SBP-pyRevit`

3. Click **Save Settings and Reload**.
4. A new **SBP** tab appears with **SBP Wall** and **SBP Count**. 

How to use it (quick start)

1. Open a **plan view**. The pile family **ICSPL_Pile** must be loaded in the project.
2. Draw the "other structure" line with **Model Line**: any shape (line, arc, circle, spline or several joined lines).
3. Select the line → **SBP** tab → **SBP Wall**.
4. Fill in the settings: wall name, pile type, level, c/c spacing, gap (min 150), Cut-off Level and Toe Levels.
5. **Click on the side** of the line where the wall should go.
6. The piles are placed, and a report shows the **HARD / SOFT / TOTAL** counts. Marks look like **SBP1-H001 / SBP1-S001**.
7. To change a wall: run SBP Wall again with the **same wall name** and confirm the rebuild.
8. **SBP Count** lists the pile counts for every wall in the model.

Getting updates

When Akash announces a new version: 1. Open **GitHub Desktop** (make sure **SBP-pyRevit** is the current repository, top left). 2. Click **Fetch origin**, then **Pull origin**. 3. In Revit: **pyRevit** → **Reload** (or restart Revit).

That's it. You don't need to download or copy anything else.

Troubleshooting

Problem	Fix
No SBP tab	Check Step 4: the folder must be <code>C:\pyRevit-Ext\SBP-pyRevit</code> (the one that contains <code>SBP.extension</code>). Then Reload.
Two SBP tabs	An old copy is in the extension list. Remove it in pyRevit Settings → Reload.
"Family 'ICSPL_Pile' is not loaded"	Load the ICSPL_Pile family into your project.
"Open a plan view first"	Switch to a floor or structural plan, then run again.
Can't see SBP-pyRevit in GitHub Desktop	Accept the GitHub invite email, then File → Clone repository again.
Something else	Send Akash a screenshot of the error window.

Please **don't edit files** in `C:\pyRevit-Ext\SBP-pyRevit`. Your changes would block updates.

Send ideas and bugs to Akash instead.