


UART debug messages available via a USB port and a 3 pin jumper for TX, RX, and GND UART connections




Size: A4

Size: A4	Date:
----------	-------

Size: A1	5
KiCad E.D.A. 10.0.3	




Rev:

Id: 2/7



Power Monitor and Supply

PMS has an INA219 current sensor
for each board/node in the
PCB. Each takes in the 5V from it's
parent board and supplies 5V to said
board's circuit (its peripherals)
thus enabling monitoring



Sheet: /PMS_APM/
File: PMS_APM.kicad_sch

Title:


Size: A4


Date:

Rev:

KiCad E.D.A. 10.0.3

Id: 4/7





Sheet: /STORAGE_APM/
File: STORAGE_APM.kicad_sch

Title:



Size: A4

Date:

KiCad E.D.A. 10.0.3

Rev:

Id: 6/7



Sheet: /AUDIO_APM/
File: AUDIO_APM.kicad_sch

Title:

Size: A4

Date:

KiCad E.D.A. 10.0.3

Rev:

Id: 7/7