© 1995-2021 Dassault Systèmes. All rights reserved.

Training an Approximation with a Simulation Job

You can train an approximation using parameters from an existing simulation job, DOE adapter, or Monte Carlo adapter.

Before you begin: Run a simulation process with a DOE or Optimization.

See Also

About Approximation Training

1. From the **Utilities** section of the action bar, click **Approximation Trainer** and drop it on the process diagram.
2. Double-click **Approximation Trainer** .

   The **Approximation Trainer Editor** opens.
3. Click the **Select Jobs** tab and do either of the following to select the simulation job on which to train your approximation:
   - Select **Content**, and select the job on which to train your approximation.
   - Select **Parameter**, and choose an object parameter representing the simulation job or create a new simulation job object parameter.

   You can review the input and output parameters for the job in the table.
4. Click the **Configure Training** tab.
5. Enter a descriptive **Approximation Object Name**.
6. Add a new configuration:

   Training an approximation requires the definition of at least one configuration. A configuration specifies an algorithm type, algorithm hyperparameters, validation type, and validation hyperparameters for a specified set of output parameters. Each output parameter can be included in only one configuration, and each configuration must include at least one output parameter.
   a. Click **Add Configuration**.
   b. From the **Algorithm** tab, configure the **Approximation Type**, along with any hyperparameters relevant to that type, such as a polynomial order for a Response Surface Model approximation.
   c. From the **Validation** tab, configure the **Validation Type** and hyperparameters.
   d. From the **Outputs** tab, select one or more output parameters to assign them to the configuration. If all parameters assigned to a configuration are reassigned to other configurations, the empty configuration is deleted.
   e. Click **OK**.
      The new configuration is created.
7. Click **OK**.