Scope

This document describes how to test USB Host PHDC example.

Preparation

Host

A board, i.e. twrk22f120m, which is running host_phdc example.

Device

A board, i.e. twrk70f120m, which is running dev_phdc_weighscale example.

Steps

Follow the steps to run the PHDC host demo.

1. Compile example.

Note: If this example runs on the MQX and SDK, STD_FP_IO needs to be set to 1 and rebuild the MQX related libraries. This STD_FP_IO can be found in rtos/mqx/mqx_stdlib/source/include/std_prv.h.

- 2. Run the host_phdc example.
- 3. Plug-in the PHDC device and you will see some attach information printed out.
- 4. The PHDC device will automatic send reports to host. You can see information of scan report number, time, value and unit of each data field in terminal tool