

BMW 3-Series and Z4 (99-05) Includes 2006 325ci/330ci Coupe and Convertible models Haynes Online Manual.

13 Hinge and lock lubrication

1 Lubricate the hinges of the hood, doors and trunk with a light general-purpose oil. Similarly, lubricate all latches, locks and lock strikers. At the same time, check the security and operation of all the locks, adjusting them if necessary (see Chapter 11).

2 Lightly lubricate the hood release mechanism and cable with a suitable grease.

© 2024 Haynes Manuals, Inc. Contact us