

BMW 3-Series and Z4 (99-05) Includes 2006 325ci/330ci Coupe and Convertible models Haynes Online Manual.

5 Cooling fan and viscous coupling (automatic transmission models) - removal and installation

Note:

A special 32 mm narrow open-ended wrench (tool number 11 5 040) will be required to remove the fan and viscous coupling assembly.

Removal

- 1 Remove the expansion rivets mounting the fan shroud to the radiator. Where plastic expansion rivets are installed, lift up the center pin, then pry the entire rivet from place.
- 2 Disconnect the cooling ducts from the shroud and remove them from the engine compartment.
- 3 Disconnect the electrical connectors from the right side of the shroud assembly.
- 4 Release the fan shroud upper retaining clips by pulling out their center pins then lift the shroud upwards and out of position.
- 5 Using the special open-ended wrench (tool number 11 5 040), unscrew the viscous coupling from the water pump and remove the cooling fan (see illustrations). Note: *The viscous coupling has a left-hand thread.* If necessary, use a strip of metal bolted to the drive pulley to counterhold the nut.

5.5a Loosen the cooling fan hub nut using the special open-ended wrench (it has a left-hand thread; turn it clockwise to loosen it) . . .



5.5b . . . and remove the cooling fan



6 Remove the retaining bolts and separate the cooling fan from the coupling noting which way direction the fan is installed.

Installation

- 7 Reinstall the fan to the viscous coupling and tighten the bolts to the torque listed in this Chapter's Specifications. Make sure the fan is installed facing the correct direction. Screw the fan onto the water pump and tighten the hub nut to the torque listed in this Chapter's Specifications. Note: If the fan is installed the wrong way the efficiency of the cooling system will be significantly reduced.
- 8 Engage the fan shroud with the lugs on the radiator and secure it in position with the retaining clips.
- 9 Reconnect the cooling ducts (where equipped) to the shroud then securely tighten its retaining screws.

© 2024 Haynes Manuals, Inc. Contact us