


BMW 3-Series 320i & 320xi (12-14), 325i, 325xi, 330i & 330xi (06) & 328i & 328xi (07-14) Haynes Online Manual

12 Radiator airflow control flaps and motor - removal and installation

- 1 Remove the front bumper (see Chapter 11).
- 2 Pry up the center pins, pry out the pushpins, then remove the mounting bolts. Remove the intake ducting from the radiator support (see illustrations).

12.2a Remove the bolts and remove the plastic pushpins




12.2b Pry up the center pins and pry out the pushpins



3 Remove the Torx bolts and the bumper bar support (see illustration) .

12.3 Remove the Torx bolts and remove the bumper bar support



4 Remove the Torx bolts, disconnect the electrical connector and pull the control flap assembly forward from the vehicle (see illustrations) .

12.4a Remove the Torx bolt on each side .



12.4b . . . and remove the control flap assembly



5 Installation is the reverse of removal.

© 2024 Haynes Manuals, Inc. Contact us