

BMW 3-Series (92-98) & Z3 (96-98) Haynes Online Manual

## 14 Oil seals - replacement

## Crankshaft front oil seal

1 <u>Oil seal</u> replacement is described as part of the lower <u>timing chain</u> cover removal and installation procedure in <u>Section 6</u>.

## Crankshaft rear oil seal

2 Proceed as described for six-cylinder engines in Chapter 2B, Section 14.

## Camshaft oil seals

3 No <u>camshaft</u> oil seals are fitted. Sealing is provided by the valve cover <u>gasket</u> and the <u>timing chain</u> cover <u>gaskets</u>.

© 2024 Haynes Manuals, Inc. Contact us