

BMW 3-Series 320i & 320xi (12-14), 325i, 325xi, 330i & 330xi (06) & 328i & 328xi (07-14) Haynes Online Manual

## 16 Flywheel pilot bearing - inspection, removal and installation

This procedure is essentially the same as for the 3.0L six-cylinder engine. Refer to part A and follow the procedure outlined there However, use the flywheel bolt torque listed in this Chapter's Specifications.

© 2024 Haynes Manuals, Inc. Contact us