

BMW 3-Series 320i & 320xi (12-14), 325i, 325xi, 330i & 330xi (06) & 328i & 328xi (07-14) Haynes Online Manual

5 Battery cables - replacement

- 1 When removing the cables, always disconnect the cable from the negative battery <u>terminal</u> first and hook it up last, or you might accidentally short out the battery with the tool you're using to loosen the cable clamps. Even if you're only replacing the cable for the positive terminal, be sure to disconnect the negative cable from the battery first.
- 2 Disconnect the old cables from the battery, then trace each of them to their opposite ends and disconnect them. Be sure to note the routing of each cable before disconnecting it to ensure correct installation.
- 3 If you are replacing any of the old cables, take them with you when buying new cables. It is vitally important that you replace the cables with identical parts.
- 4 Clean the threads of the <u>solenoid</u> or ground connection with a wire brush to remove rust and corrosion. Apply a light coat of battery <u>terminal</u> corrosion inhibitor or petroleum jelly to the threads to prevent future corrosion.
- 5 Attach the cable to the solenoid or ground connection and tighten the mounting nut/bolt securely.
- 6 Before connecting a new cable to the battery, make sure that it reaches the battery post without having to be stretched.
- 7 Installation is the reverse of removal. Connect the positive cable first, then the negative cable. Refer to <u>Section</u> <u>3</u> and perform the sunroof and power window initialization procedures.

© 2024 Haynes Manuals, Inc. Contact us