

BMW 3-Series (92-98) & Z3 (96-98) Haynes Online Manual

12 Brake booster - general information

1 It is not possible for the home mechanic to remove the <u>brake booster</u>. If the hydraulic unions are disconnected from the <u>master cylinder</u>, air will enter the high-pressure hydraulic system linking the master cylinder, hydraulic unit. <u>Bleeding</u> of the high-pressure system can only be safely carried out by a BMW dealer who has access to the service tester (see <u>Section 2</u>). The <u>brake booster</u> can be tested (see steps 3 through 5 in <u>Section 13</u>), but removal and installation should be entrusted to a BMW dealer or other qualified repair shop.

© 2024 Haynes Manuals, Inc. Contact us