

BMW 3-Series and Z4 (99-05) Includes 2006 325ci/330ci Coupe and Convertible models Haynes Online Manual.

9 Rear brake pad check

- 1 Loosen the front wheel bolts. Chock the front wheels, then raise the rear of the vehicle and support it securely on jackstands. Remove the rear wheels.
- 2 For a quick check, the thickness of friction material remaining on each brake pad can be measured through the top of the <u>caliper</u> body (see illustration 8.2) . If any pad's friction material thickness is not within specification, all four pads must be replaced as a set.
- 3 For a comprehensive check, the <u>brake pads</u> should be removed and cleaned. This will permit the operation of the <u>caliper</u> to be checked, and the condition of the <u>brake disc</u> itself to be fully examined on both sides. Refer to Chapter 9 for further information.

© 2024 Haynes Manuals, Inc. Contact us