

BMW 3-Series and Z4 (99-05) Includes 2006 325ci/330ci Coupe and Convertible models Haynes Online Manual.

## **Specifications**

## Lubrication

Oil capacity	See <u>Chapter 1</u>	
	Ft-lbs (unless otherwise indicated)	Nm
Torque wrench settings		
Transmission crossmember-to- body bolts		
M8 bolts	15	21
M10 bolts	31	42
Transmission mounting-to- transmission nuts		
M8 nuts	15	21
M10 nuts	31	42
Transmission-to-engine bolts		
Hexagon head bolts		
M8 bolts	18	25
M10 bolts	36	49
M12 bolts	55	74
Torx head bolts		
M8 bolts	16	22
M10 bolts	32	43
M12 bolts	53	72
Oil drain plug	37	50
Oil filler/level plug	37	50
Output flange-to-output shaft nut*		
Stage 1	140	190

12/8/24, 12:12 PM Haynes Online - BMW 3-Series and Z4 (99-05) Includes 2006 325ci/330ci Coupe and Convertible models Haynes Online Manual.

Stage 2 Remove nut and apply locking compound

Stage 3 89 120

Back-up light switch 15 21

© 2024 Haynes Manuals, Inc. Contact us

<sup>\*</sup> Coat the threads of the nut with thread-locking compound.