

BMW 3-Series (92-98) & Z3 (96-98) Haynes Online Manual

Inspection II

Carry out all the operations listed under Inspection I, along with the following:

Replace the spark plugs (Section 23)

Replace the air filter element (Section 24)

Replace the automatic transmission fluid (Section 25)

Replace the differential oil (Section 26)

Check the condition of the driveaxle boots (Section 27)

Check the condition of the parking brake shoe linings (Section 28)

Reset the service interval display (Section 4)

© 2024 Haynes Manuals, Inc. Contact us