Live View Troubleshooting

Live View Troubleshooting

This guide provides solutions for common live view issues in GCXONE.

Streams Not Starting

Symptoms:

- Live view shows loading spinner but no video
- "Unable to start stream" error
- Black screen in live view window

Quick fixes:

- Verify device is online
- Check streaming configuration
- Verify user permissions
- Test network connectivity

Poor Stream Quality

Symptoms:

- Pixelated or blurry video
- Low resolution display
- Poor image quality

Quick fixes:

- Increase stream quality setting
- Check bandwidth availability
- Verify using primary stream and not sub-stream
- Enable Local Mode for better quality

Layout Issues

Symptoms:

- Layouts not displaying correctly
- Cameras in wrong positions
- Layouts not saving

Layout Configuration Error

- Verify cameras are assigned to layout positions
- Check grid size matches number of cameras
- Recreate layout if corrupted
- Clear browser cache and reload

Camera Not Available

- Verify camera is online
- Check camera permissions
- Remove unavailable cameras from layout
- Replace with available cameras

Layout Not Saved

- Verify user has layout management permissions
- Check if layout name already exists
- Try a different layout name
- Save layout again

Performance Issues

Symptoms:

- Slow stream startup
- Laggy or choppy video
- System performance degradation with multiple streams

Quick fixes:

- Limit concurrent streams: Reduce number of simultaneous streams
- Use grid view efficiently: Do not exceed system capabilities
- Enable Local Mode for on-site workstations
- Close unused streams when not viewing

Multi-Camera View Problems

Symptoms:

- Grid view not working
- Cameras not displaying in grid
- Layout switching issues

Too Many Concurrent Streams

- Reduce number of cameras in grid
- Use smaller grid size such as 2x2 instead of 4x4
- Use secondary streams for grid views
- Limit concurrent streams per layout

Grid Configuration Issue

- Verify grid size is appropriate
- Check camera assignments to grid positions
- Recreate layout with correct configuration
- Verify all cameras in layout are available

Performance Limitations

- Check system resources including CPU, memory, and network
- Reduce stream quality for grid views
- Use Local Mode if available
- Upgrade hardware if needed

PTZ Controls Not Available in Live View

Symptoms:

- PTZ controls not visible in live view
- PTZ buttons disabled
- Cannot control camera from live view

Quick fixes:

- Verify camera supports PTZ
- Check PTZ is enabled on device
- Verify user has PTZ permissions
- Enable PTZ controls in live view settings

Still Having Issues?

1. Check Video Streaming Troubleshooting — many live view issues are streaming-related
2. Gather information including device types, error messages, and network configuration
3. Review GCXONE and device logs for errors
4. Contact Support and submit a support ticket with details