
4. Control Module I/O Signal

A: ELECTRICAL SPECIFICATION



| Terminal No. | Content | Measured value and measuring conditions | Remarks |
|--------------|-----------------------|--|--------------|
| 1 | _ | _ | _ |
| 2 | | _ | _ |
| 3 | | _ | _ |
| 4 | Ignition power supply | 10 — 13 V (when the ignition switch is ON) | _ |
| 5 | GND | 0 V (always) | _ |
| 6 | Battery power supply | 10 — 13 V (always) | |
| 7 | | _ | |
| 8 | | _ | |
| 9 | | _ | |
| 10 | 1 | _ | - |
| 11 | Body integrated unit | _ | - |
| 12 | _ | _ | - |

B: WIRING DIAGRAM

Refer to "Tire Pressure Monitoring System" in the wiring diagram. <Ref. to WI(w/o HEV)-218, WIRING DIAGRAM, Tire Pressure Monitoring System.> <Ref. to WI(HEV)-212, WIRING DIAGRAM, Tire Pressure Monitoring System.>