8. General Diagnostic Table

A: INSPECTION

Symptoms	Possible cause	Corrective action	
Select lever	Starter does not run.	Adjust the select cable and inhibitor switch, or inspect the circuit.	
	Back-up light does not illuminate.	Adjust the select cable and inhibitor switch, or inspect the circuit.	
	AT shift lock system does not operate normally.	Adjust the select cable and inhibitor switch, or inspect the circuit.	
	Manual mode can not be set.	Inspect the mode switch and select lever, or inspect the circuit.	
	Up-shift is not engaged at manual mode.	Check the shift-up switch and circuit.	
	Down-shift is not engaged at manual mode.	Check the shift-down switch and circuit.	

CONTINUOUSLY VARIABLE TRANSMISSION

CVT(TR580)

		Page
1.	General Description	
2.	CVTF	
3.	Differential Gear Oil	
4.	AWD ON/OFF Switching Mode	
5.	Road Test	
6.	Stall Test	
7.	Time Lag Test	
8.	Secondary Pressure (Line Pressure) Test	
9.	Transfer Clutch Pressure Test	
10.	Automatic Transmission Assembly	
11.	Transmission Mounting System	
12.	Extension Case Oil Seal	
13.	Differential Side Retainer Oil Seal	
14.	Inhibitor Switch	
15.	Turbine Speed Sensor	
16.	Secondary Speed Sensor	
17.	Primary Speed Sensor	
18.	Secondary Pressure Sensor	
19.	Oil Pan and Strainer	
20.	Control Valve Body	
21.	Transmission Harness	
22.	Transmission Control Module (TCM)	
23. 24.	CVTF Cooler (With Warmer Function)	
24. 25.	Air Breather Hose Drive Plate	
25. 26.	Torque Converter Assembly	
20. 27.	Preparation for Overhaul	
27. 28.	Extension Case	
20. 29.	Transfer Clutch	
29. 30.	Transfer Driven Gear	
30. 31.	Parking Pawl	
32.	Reduction Driven Gear	
33.	Transmission Control Device	
34.	Transmission Case	
35.	CVTF Filter	
36.	Reduction Drive Gear	
37.	Primary Pulley and Secondary Pulley	
38.	Variator Chain	
39.	Reverse Brake Assembly	
40.	Forward Clutch Assembly	
41.	Drive Pinion Shaft Assembly	
42.	Front Differential Assembly	
43.	Oil Pump Chain	
44.	Oil Pump	
45.	Converter Case	
46.	Diagnostics with Phenomenon	