## **59.Bulkhead Wiring Harness (In Engine Compartment)**

## A: LOCATION

Connector				Connecting to			
No.	Pole	Color	Area	No.	Description		
B3	5	Black	B-2		Mass air flow and intake air temperature sensor		
B6	2	Light gray	C-3		Front ABS wheel speed sensor RH		
B8	5	Light gray	B-5		Front wiper motor		
B10	4	Light gray	C-4		Pressure switch		
B11	12	Light gray	B-4	T4	- Transmission cord (CVT model)		
B12	16	Dark gray	B-4	T3			
B14	1	Black	C-4		Starter motor		
B15	2	Light gray	C-4		Front ABS wheel speed sensor LH		
B16	2	Gray	B-4		Brake fluid level switch		
B21	54	Black	B-3	E2	Engine wiring harness		
B22	16	Brown	B-3				
B24	2	Gray	B-3	T1	Back-up light switch (MT model)		
B25	2	Brown	B-3	T2	Neutral position switch 1		
B143	20	*	B-5				
B144	9	Brown	B-5		M/B		
B145	7	Brown	B-5				
B146	2	Black	C-4		Front washer motor		
B147	2	Gray	C-4		Rear washer motor		
B164	2	Gray	B-2		Keyless buzzer		
B177	2	Gray	B-4		Wiper deicer		
B186	8	*	B-5		M/B		
B310	26	Black	B-2		VDC CM (with EyeSight)		
	38	*	B-2		VDC CM (without EyeSight)		
B321	2	Black	B-3		Hood switch		
B360	16	Gray	B-4	F109	Through joint connector		
B361	14	*	B-4	F108	Through joint connector		
B396	2	Brown	D-3		Washer fluid level sensor		
B432	8	Black	C-4		SBF holder		
B450	10	Black	C-3		Power steering CM		
B451	6	Gray	B-3		Torque sensor		
B452	2	Black	B-3		Power steering CM		
B523	2	Light gray	C-5		Battery temperature sensor		
B538	3	Black	C-4		Battery current sensor		
B567	26	*	B-3		Relay holder		
B571	2	*	B-5		M/B		
★: White or natural color							

Connector				Connecting to		
No.	Pole	Color	Area	No.	Description	
AB13	2	Yellow	C-3		Front sub sensor LH	
AB16	2	Yellow	B-1		Front sub sensor RH	

