## 5. General Diagnostic Table

## A: INSPECTION

| Symptoms         | Possible cause                               | Corrective action  |
|------------------|--|--------------------|
|                  | Lever assembly - hand brake is maladjusted.  | Adjust.            |
| Brake dragging   | Parking brake cable does not move.           | Repair or replace. |
|                  | Parking brake shoe clearance is maladjusted. | Adjust.            |
|                  | Spring - shoe return is faulty.              | Replace.           |
| Noise from brake | Spring - shoe return is faulty.              | Replace.           |
|                  | Cup - shoe hold-down is faulty.              | Replace.           |

## POWER ASSISTED SYSTEM (POWER STEERING)

## PS

|    |                                 | Page |
|----|---------------------------------|------|
| 1. | General Description             | 2    |
|    | Power Steering System           |      |
|    | Steering Wheel                  |      |
|    | Universal Joint                 |      |
| 5. | Steering Column                 | 19   |
|    | Electric Power Steering Gearbox |      |
|    | Power Steering Control Module   |      |
|    | General Diagnostic Table        |      |