

3. Power Supply Circuit

A: WIRING DIAGRAM

- 1. WITHOUT PUSH BUTTON START
- Engine room side


P-SUP-01








· Passenger room side


P-SUP-02




















No.	Load
MB-1	VDC CM
MB-2	VDC CM
MB-3	Wiper relay
1,415	Brake vacuum pump relay
MB-4	Sub fan relay
MB-5	Mirror heater LH
IVID 0	Mirror heater RH
	Rear defogger
MB-6	Body integrated unit
MB-7	Main fan relay 2
MB-8	Main fan motor
MB-9	ECM
MB-10	Main fan relay 2
MB-11	Main fan relay 2
MB-11	Body integrated unit
MB-13	Body integrated unit
MB-16	Front combination light LH
IVID-10	Front combination light RH
MB-17	5
MB-18	Daytime running light relay
	Body integrated unit Horn
MB-19 MB-20	
	Horn
MB-21	Horn switch
MD 00	Body integrated unit
MB-22	A/F, oxygen sensor relay
MB-23	Main relay
MD 04	IG relay
MB-24	Electronic throttle control relay
MB-25	Fuel pump relay
MB-26	TCM
140.07	Self shut relay
MB-27	ECM
	Data link connector
MB-28	Key warning switch
	Turn signal and hazard unit
	Body integrated unit
MB-29	Spot map light
	Room light
	Body integrated unit
	Immobilizer antenna
MB-30	Power window circuit breaker
MB-32	Tail relay
	Daytime running light relay
MB-33	DMCM relay
	High voltage battery cooling fan/drive motor
	inverter relay
	High voltage battery
	HPCM
NAD CC	ISG
MB-36	HPCM


No.	Load
MB-37	Brake vacuum pump relay
ST-1	Starter relay 1
ST-2	Starter relay 1
	HPCM
FB-3	Stop light and brake switch
FB-4	Wiper deicer relay
FB-5	Seat heater relay
FB-6	Body integrated unit
FB-8	Blower motor relay
FB-9	Front fog light relay
FB-10	Audio
	MFD
	Navigation unit
FB-12	Keyless entry CM
	Luggage room light
FB-18	Combination meter
	Body integrated unit
	Impact sensor
	Air mix door actuator LH (with left/right inde-
	pendent air conditioner)
	Air mix door actuator RH (with left/right inde-
	pendent air conditioner)
	Mode door actuator
	Air mix door actuator (without left/right independent air and sitting as)
	dent air conditioner)
	Security CM
	A/C control panel
FB-19	Active grille shutter Remote control mirror switch
FB-19	
FB-20	Seat heater relay Rear view mirror
FB-21	Rear accessory power supply socket
FB-22	Front accessory power supply socket
FB-25	
FD-25	AUX input terminal Audio
	Navigation unit
FB-28	A/C control panel
FB-29	Body integrated unit
FB-30	Pedestrian alert CM
FB-32	Impact sensor
1 0-02	Data link connector
	Stop light and brake switch
	Wiper deicer relay
	Sunroof motor assembly
	Sunroof switch
	Sunroof switch (tilt)
FB-34	Turn signal and hazard unit
FB-35	Back-up light relay
טיבט ו	Auto headlight beam leveler CM
	Auto Headily III Death leveler CIVI


No.	Load
FB-36	Combination meter
	MFD
	HPCM
FB-38	HPCM
	DMCM
	High voltage battery
	Electric oil pump inverter
	ECM
	TCM
	Body integrated unit
	Fuel pump relay
FB-41	Airbag CM
FB-42	Power window relay
	Wiper relay
FB-44	VDC CM
	Steering angle sensor
	Power steering CM
FB-45	A/C control panel
FB-46	A/C relay
	Sub fan relay
	Pressure switch
	Blower motor relay
FB-47	Occupant detection control module
FB-48	TPMS & keyless entry CM
BAT-1	12V engine restart battery sensor
BAT-2	Power steering CM
BAT-3	DC/DC converter

2. WITH PUSH BUTTON START

• Engine room side


P-SUP(P)-01







• Passenger room side


P-SUP(P)-02








RELAY HOLDER RELAY HOLDER








1 2 3 4 5 6 7 8 9 10 11 12 13 14 15 16 17 18 19 20

1 2 3 4 5 6 7 8 9 10 11 12

1 2 3 4 5 6 7 8







Na	Load
No.	Load
MB-1	VDC CM
MB-2	VDC CM
MB-3	Wiper relay
	Brake vacuum pump relay
MB-4	Sub fan relay
MB-5	Mirror heater LH
	Mirror heater RH
	Rear defogger
MB-6	Body integrated unit
MB-7	Main fan relay 2
MB-8	Main fan motor
MB-9	ECM
MB-10	Main fan relay 2
MB-11	Main fan relay 2
MB-12	Body integrated unit
MB-13	Body integrated unit
MB-16	Front combination light LH
	Front combination light RH
MB-17	Daytime running light relay
MB-18	Body integrated unit
MB-19	Horn
MB-20	Horn
MB-21	Horn switch
	Body integrated unit
MB-22	A/F, oxygen sensor relay
MB-23	Main relay
	IG relay
MB-24	Electronic throttle control relay
MB-25	Fuel pump relay
MB-26	TCM
	Self shut relay
MB-27	ECM
	Data link connector
MB-28	Turn signal and hazard unit
	Body integrated unit
MB-29	Spot map light
IVID 23	Room light
	Body integrated unit
	Immobilizer antenna
MB-30	Power window circuit breaker
MB-31	IG relay 1 (push button start)
ו פ-טועו	
	IG relay 2 (push button start)
MD 00	Accessory relay (push button start)
MB-32	Tail relay
	Daytime running light relay

No.	Load
MB-33	DMCM relay
	High voltage battery cooling fan / drive motor inverter relay
	High voltage battery
	HPCM
	ISG
MB-35	ID code box
	Keyless access CM
MB-36	HPCM
MB-37	Brake vacuum pump relay
ST-2	Starter relay 1
FB-3	Stop light and brake switch
FB-4	Wiper deicer relay
FB-5	Seat heater relay
FB-6	Body integrated unit
FB-7	Remote engine start CM
FB-8	Blower motor relay
FB-9	Front fog light relay
FB-10	Audio
	MFD
	Navigation unit
FB-12	Keyless entry CM
	Luggage room light
FB-18	Combination meter
	Body integrated unit
	Impact sensor
	Air mix door actuator LH (with left/right inde-
	pendent air conditioner) Air mix door actuator RH (with left/right inde-
	pendent air conditioner)
	Mode door actuator
	Air mix door actuator (without left/right independent air conditioner)
	Steering lock CM
	A/C control panel
	Active grille shutter
FB-19	Remote control mirror switch
FB-20	Seat heater relay
	Rear view mirror
FB-21	Rear accessory power supply socket
FB-22	Front accessory power supply socket
FB-25	AUX input terminal
	Audio
	Navigation unit
FB-28	A/C control panel
FB-29	Body integrated unit
FB-30	Pedestrian alert CM

No.	Load
FB-32	Remote engine start CM
	Impact sensor
	Data link connector
	Stop light and brake switch
	Wiper deicer relay
	Sunroof motor assembly
	Sunroof switch
	Sunroof switch (tilt)
FB-34	Turn signal and hazard unit
FB-35	Back-up light relay
	Auto headlight beam leveler CM
FB-36	Combination meter
	MFD
	HPCM
FB-38	HPCM
	DMCM
	High voltage battery
	Electric oil pump inverter
	Keyless access CM
	ECM
	TCM
	Body integrated unit
	Fuel pump relay
FB-41	Airbag CM
FB-42	Power window relay
	Wiper relay
FB-43	Steering lock CM
FB-44	VDC CM
	Steering angle sensor
	Power steering CM
FB-45	A/C control panel
FB-46	A/C relay
	Sub fan relay
	Pressure switch
	Blower motor relay
FB-47	Occupant detection control module
FB-48	TPMS CM
BAT-1	12V engine restart battery sensor
BAT-2	Power steering CM
BAT-3	DC/DC converter