

Nimbus 500 Mesh Access Point

Installation and administration manual, revision 2.8, published 28 January 2026.

1. What is in the box

Each Nimbus 500 ships with the access point, a ceiling bracket, four wall plugs and screws, a Cat 6 patch cable, and a quick start card. The PoE injector is a separate order line and is not included in the standard bundle.

2. Mounting

Mount the unit on a ceiling or a high wall, at least 2.4 metres above the floor and clear of metal ducting. Keep two metres between neighbouring access points on the same floor and stagger units on adjacent floors so their cells do not stack vertically.

3. First-time setup

Connect the access point to a PoE+ switch port. The status light pulses amber while the unit boots and turns solid white when it has joined a controller. Adopt the unit in the Northwind Device Portal under Network, then Access points, then Adopt, and enter the serial number printed on the base.

4. Radio configuration

Band	Standard	Channel width	Recommended use
2.4 GHz	Wi-Fi 6	20 MHz	Legacy devices, sensors, badge readers
5 GHz	Wi-Fi 6	80 MHz	Laptops and phones, primary client band
6 GHz	Wi-Fi 6E	160 MHz	Conference rooms, high-density areas

Leave automatic channel selection on unless a site survey says otherwise. Manual channel plans drift out of date as neighbouring tenants change their own networks.

5. Status light reference

Light	Meaning	Action
Solid white	Adopted and healthy	None
Pulsing amber	Booting or upgrading firmware	Wait up to five minutes
Solid amber	No controller reachable	Check uplink and VLAN tagging
Flashing red	Insufficient power	Move to a PoE+ port or add an injector
Off	No power	Check the switch port and cable

6. Firmware

Firmware updates are published monthly and applied during the maintenance window configured for the site. A unit takes roughly four minutes to update and rejoins the mesh automatically. Do not power cycle a unit while the light is pulsing amber.

7. Factory reset

Hold the recessed reset button for ten seconds until the light flashes red twice. The unit clears its configuration, returns to the unadopted state, and must be adopted again in the device portal.