

Poor handling or stability

46 Handlebar hard to turn

- 1 Steering stem nut too tight (Chapter 6).
- 2 Bearings damaged. Roughness can be felt as the bars are turned from side-to-side. Replace bearings and races (Chapter 6).
- 3 Races dented or worn. Denting results from wear in only one position (e.g., straight-ahead), from a collision or hitting a pothole or from dropping the machine. Replace races and bearings (Chapter 6).
- 4 Steering stem lubrication inadequate. Causes are grease getting hard from age or being washed out by high pressure car washes. Disassemble steering head and repack bearings (Chapter 6).
- 5 Steering stem bent. Caused by a collision, hitting a pothole or by dropping the machine. Replace damaged part. Don't try to straighten the steering stem (Chapter 6).
- 6 Front tire air pressure too low (Chapter 1).

47 Handlebar shakes or vibrates excessively

- 1 Tires worn or out of balance (Chapter 7).
- 2 Swingarm bearings worn. Replace worn bearings by referring to Chapter 6.
- 3 Rim(s) warped or damaged. Inspect wheels for runout (Chapter 7).
- 4 Wheel bearings worn. Worn front or rear wheel bearings can cause poor tracking. Worn front bearings will cause wobble (Chapter 7).
- 5 Handlebar clamp bolts loose (Chapter 6).
- 6 Steering stem or fork triple clamps loose. Tighten them to the specified torque (Chapter 6).
- 7 Engine mounting bolts loose. Will cause excessive vibration with increased engine rpm (Chapter 2).
- 8 Loose axle (Chapter 7).

48 Handlebar pulls to one side

- 1 Frame bent. Definitely suspect this if the machine has been dropped. May or may not be accompanied by cracking near the bend. Replace the frame (Chapter 6).
- 2 Wheel out of alignment. Caused by improper location of axle spacers or from bent steering stem or frame (Chapter 6).
- 3 Swingarm bent or twisted. Caused by age (metal fatigue) or impact damage. Replace the arm (Chapter 6).
- 4 Steering stem bent. Caused by impact damage or by dropping the motorcycle. Replace the steering stem (Chapter 6).
- 5 Fork leg bent. Disassemble the forks and replace the damaged parts (Chapter 6).
- 6 Fork oil level uneven. Check and add or drain as necessary (Chapter 6).
- 7 Defective shock absorber on one side (Magna models).

49 Poor shock absorbing qualities

- 1 Too hard:
 - a) Fork oil level excessive (Chapter 6).
 - b) Fork oil viscosity too high.
 - c) Fork tube bent. Causes a harsh, sticking feeling (Chapter 6).
 - d) Anti-dive passages clogged (Chapter 6).
 - e) Shock shaft or body bent or damaged (Chapter 6).
 - f) Fork internal damage (Chapter 6).
 - g) Shock internal damage.
 - h) Tire pressure too high (Chapter 1).

2 Too soft:

- a) Fork or shock oil insufficient and/or leaking (Chapter 6).
- b) Fork oil level too low (Chapter 6).
- c) Fork oil viscosity too light (Chapter 6).
- d) Fork springs weak or broken (Chapter 6).
- e) Shock internal damage or leakage (Chapter 6).

Braking problems

50 Disc brakes are spongy, don't hold

- 1 Air in brake line. Caused by inattention to master cylinder fluid level or by leakage. Locate problem and bleed brakes (Chapter 7).
- 2 Pad or disc worn (Chapters 1 and 7).
- 3 Brake fluid leak. See paragraph 1.
- 4 Contaminated pads. Caused by contamination with oil, grease, brake fluid, etc. Clean or replace pads. Clean disc thoroughly with brake cleaner (Chapter 7).
- 5 Brake fluid deteriorated. Fluid is old or contaminated. Drain system, replenish with new fluid and bleed the system (Chapter 7).
- 6 Master cylinder internal parts worn or damaged causing fluid to bypass (Chapter 7).
- 7 Master cylinder bore scratched by foreign material or broken spring. Repair or replace master cylinder (Chapter 7).
- 8 Disc warped. Replace disc (Chapter 7).

51 Brake lever or pedal pulsates

- 1 Disc warped or drum out-of-round (Chapter 7).
- 2 Axle bent. Replace axle (Chapter 7).
- 3 Brake caliper or bracket bolts loose (Chapter 7).
- 4 Brake caliper sticking on its mounting bolt shafts, causing caliper to bind. Lube the shafts or replace them if they are corroded or bent (Chapter 7).
- 5 Wheel warped or otherwise damaged (Chapter 7).
- 6 Wheel bearings damaged or worn (Chapter 7).

52 Brakes drag

- 1 Master cylinder piston seized. Caused by wear or damage to piston or cylinder bore (Chapter 7).
- 2 Lever balky or stuck. Check pivot and lubricate (Chapter 7).
- 3 Brake caliper binds. Caused by inadequate lubrication or damage to caliper sliders (Chapter 7).
- 4 Brake caliper pistons seized in bore. Caused by wear or ingestion of dirt past deteriorated seal (Chapter 7).
- 5 Brake pad damaged. Pad material separated from backing plate. Usually caused by faulty manufacturing process or from contact with chemicals. Replace pads (Chapter 7).
- 6 Pads improperly installed (Chapter 7).
- 7 Drum brake operating cam sticking or broken/sagged shoe return springs (Chapter 7).
- 8 Rear brake pedal freeplay insufficient.

Electrical problems 53

Battery dead or weak

- 1 Battery faulty. Caused by sulfated plates which are shorted through sedimentation or low electrolyte level. Also, broken battery terminal making only occasional contact (Chapter 8).
- 2 Battery cables making poor contact (Chapter 8).

3 Load excessive. Caused by addition of high wattage lights or other electrical accessories.

4 Ignition main (key) switch defective. Switch either grounds (earths) internally or fails to shut off system. Replace the switch (Chapter 8).

5 Regulator/rectifier defective (Chapter 8).

6 Alternator stator coil open or shorted (Chapter 8).

7 Wiring faulty. Wiring grounded (earthed) or connections loose in ignition, charging or lighting circuits (Chapter 8).

54 Battery overcharged

1 Regulator/rectifier defective. Overcharging is noticed when battery gets excessively warm or boils over (Chapter 8).

2 Battery defective. Replace battery with a new one (Chapter 8).

3 Battery amperage too low, wrong type or size. Install manufacturer's specified amp-hour battery to handle charging load (Chapter 8).

Chapter 1

Tune-up and routine maintenance

Contents

	Sect/on		Sect/on
Air filter element - cleaning and replacement.....	12	Final drive unit - oil change.....	11
Battery - check.....	4	Fluid levels - check.....	3
Brake pads/linings - wear check.....	5	Fuel system - checks and filter replacement.....	26
Brake system - checks.....	6	Idle speed - check and adjustment.....	17
Carburetor synchronization - check and adjustment.....	18	Introduction to tune-up and routine maintenance.....	2
Clutch - checks and bleeding.....	9	Lubrication - general.....	15
Cooling system - check.....	19	Routine maintenance intervals.....	1
Cooling system - draining, flushing and refilling.....	20	Spark plugs - check and replacement.....	14
Crankcase breather - check.....	21	Stands - check.....	28
Cylinder compression - check.....	13	Steering head bearings - check and adjustment.....	24
Engine oil/filter - change.....	10	Suspension - check.....	27
Evaporative emission control system and Secondary air supply system (California models only) - check.....	22	Tires/wheels - general check.....	7
Exhaust system - check.....	23	Throttle and choke operation/grip freeplay - check and adjustment.....	8
Fasteners - check.....	25	Valve clearances - check and adjustment.....	16

Specifications

Engine

Spark plug type	
Standard.....	NGK DPR8EA-9 or ND X24EPR-U9
Below 41°F (5°C).....	NGK DPR7EA-9 or ND X22EPR-U9
Extended high speeds.....	NGK DPR9EA-9 or ND X27EPR-U9
Spark plug electrode gap.....	0.8 to 0.9 mm (0.031 to 0.035 in)
Valve clearances (COLD engine)	
1982 through 1984 700/750 Magnas and all 700/750 Sabre models.....	0.12 mm (0.0047 in)
1985 700 Magna models.....	0.13 mm (0.0051 in)
1986-on 700/750 and all 1100 models.....	0.15 mm (0.0059 in)
Engine idle speed	
750 Sabre and 1982 through 1984 700/750 Magna models.....	1000 ± 100 rpm
700 Sabre and 1985-on 700/750 Magna models.....	1200 ± 100 rpm
1100 Sabre models.....	1000 to 1100 rpm
1100 Magna models.....	1000 ± 100 rpm
Cylinder compression pressures.....	184 ± 28 psi (psi)
Carburetor synchronization (maximum vacuum difference between any two cylinders)	
1985 through 1988 700/750 Magna models.....	40 mm (1.6 in) Hg
All other models.....	60 mm (2.4 in) Hg
Cylinder identification.....	See illustration 1.1 in Chapter 2

Miscellaneous

Battery electrolyte specific gravity.....	1.280 at 68°F (20°C)
Brake pad minimum thickness.....	See text
Brake pedal freeplay (700/750 models).....	20 to 30 mm (0.8 to 1.2 in)
Throttle grip freeplay.....	2 to 6 mm (0.08 to 0.24 in)

Tire sizes

	Front	Rear
700/750 Sabre models.....	110/90-18 61H	130/90-17 68H
1982 through 1984 700/750 Magna models.....	110/90-18 61H	130/90-16 67H
1985 and 1986 700/750 Magna models.....	110/90-18 61H	140/90-15 70H
1987 and 1988 700/750 Magna models.....	100/90-19 57H	150/80-15 70H
1100 Sabre models.....	M110/90-18	M130/90-17
1100 Magna models.....	M110/90-18	M140/90-16
Minimum tire tread depth*.....	1.5 mm (0.06 in)	2.0 mm (0.08 in)
Tire pressures (cold)		
1100 Sabres		
Up to 90 kg (200 lb) load.....	32 psi	36 psi
Over 90 kg (200 lb) load.....	32 psi	40 psi
700/750 Sabres, 1982 through 1984 700/750 Magnas, all 1100 Magnas		
Up to 90 kg (200 lb) load.....	32 psi	32 psi
Over 90 kg (200 lb) load.....	32 psi	40 psi
1985 through 1988 700/750 Magnas		
Up to 90 kg (200 lb) load.....	32 psi	32 psi
Over 90 kg (200 lb) load.....	32 psi	42 psi

In the UK, tread depth must be at least 1 mm over 3/4 of the tread breadth all the way around the tire, with no bald patches.

Torque setting

	Nm	ft-lbs
Engine oil pan drain plug.....	35 to 40	25 to 29
Front cylinder oil drain plug.....	10 to 14	7 to 10
Oil filter (using Honda tool).....	15 to 20	11 to 14
Spark plugs.....	12 to 16	9 to 12

Recommended lubricants and fluids

Engine/transmission oil	
Type.....	API grade SE or SF
Viscosity.....	SAE10W/40
Capacity (700/750 models)	
After draining.....	2.9 lit (3.1 US qt, 5.1 imp pts)
After engine rebuild.....	3.0 lit (3.2 US qt, 5.3 imp pts)
Capacity (1100 models)	
After draining.....	3.0 lit (3.2 US qt, 5.3 imp pts)
After engine rebuild.....	3.5 lit (3.7 US qt, 6.2 imp pts)
Final drive unit	
Type	
1982 and 1983 750 models (above 41°F/5°C).....	Hypoid gear oil SAE90
1982 and 1983 750 models (below 41°F/5°C).....	Hypoid gear oil SAE80
All other models.....	Hypoid gear oil SAE80
Capacity*	
1982 and 1983 750 models.....	110 cc (3.7 US fl oz, 3.9 imp fl oz)
1984-on 700/750 models and all 1100 models.....	130 cc (4.4 US fl oz, 4.6 imp fl oz)

**Refill quantity is greater if the final drive has been dismantled*

Coolant		
Mixture type.....	50% distilled water, 50% corrosion inhibited ethylene glycol antifreeze	
Radiator capacity		
700/750 models.....	2.4 lit (2.5 US qt, 4.2 imp pt)	
1100 Sabre model.....	2.8 lit (2.9 US qt, 4.9 imp pt)	
1100 Magna model.....	3.0 lit (3.2 US qt, 5.3 imp pt)	
Reservoir tank capacity (approx.)		
1100 Sabre model.....	0.6 lit (0.6 US qt, 1.0 imp pt)	
All other models.....	0.4 lit (0.4 US qt, 0.7 imp pt)	
Brake and clutch fluid.....	DOT 3 or 4 (see reservoir cap)	

Miscellaneous

Wheel bearings.....	Medium weight, lithium-based multi-purpose grease
Final drive flange grease.....	See Chapter 6
Swingarm pivot bearings (Sabre).....	Molybdenum disulfide grease
Suspension linkage bearings (Sabre).....	Molybdenum disulfide grease
Cables and lever pivots.....	Chain and cable lubricant or 10W40 motor oil
Stand pivots.....	Medium-weight, lithium-based multi-purpose grease
Brake pedal/shift lever pivots.....	Chain and cable lubricant or 10W40 motor oil
Throttle grip.....	Multi-purpose grease or dry film lubricant

1 Honda 700, 750 & 1100 V-Four

Routine maintenance intervals

Routine maintenance intervals

Note: The pre-ride inspection outlined in the owner's manual covers the checks and maintenance that should be carried out on a daily basis. It's condensed and included here to remind you of its importance. Always perform the pre-ride inspection at every maintenance interval (in addition to the procedures listed). The intervals listed below are the shortest intervals recommended by the manufacturer for each particular operation during the model years covered in this manual. Your owner's manual may have different intervals for your model.

Daily or before riding

Check the engine oil level
Check the fuel level and inspect for leaks
Check the engine coolant level and look for leaks
Check the operation of both brakes - also check the fluid levels and look for leakage Check the tires for damage, the presence of foreign objects and correct air pressure Check the throttle for smooth operation Check the operation of the clutch - make sure the freeply is correct Make sure the steering operates smoothly, without looseness or binding Check for proper operation of the headlight, taillight, brake light, turn signals, indicator lights, speedometer and horn Make sure the sidestand and main stand return to their fully up positions and stay there under spring pressure Make sure the engine stop switch works properly

After the initial 600 miles (1000 km)

Replace the engine oil and oil filter
Check and adjust the valve clearances Check and adjust the idle speed Check the throttle operation Check the carburetor synchronization Check the cooling system Check the brake hydraulic system Check the clutch hydraulic system Check the tightness of all fasteners Check the steering head bearings

Every 4000 miles (6000 km)

Clean the air filter element(s) (Sabre models) Drain the crankcase breather separator tank (where applicable)

Replace the spark plugs
Check the idle speed
Check the battery electrolyte level and condition
Check the brake fluid level and pad wear
Check the drum brake lining wear
Check the clutch fluid level

Every 8000 miles (12,000 km)


Replace the engine oil and filter
Check the fuel system hoses
Check the battery
Check and adjust the throttle and choke cables
Check/adjust the valve clearances
Replace the air cleaner element (1982 through 1985 Magna models)
Check/adjust the carburetor synchronization Check the Evaporative emission control system (1982 through 1985 models) Check the Secondary air supply system (1986 through 1988 models)
Check the coolant level and check the cooling system
Check the final drive oil level Lubricate the final drive flange with fresh grease - 700/750 Sabres and 1982 through 1984 700/750 Magnas (see Chapter 6)
Check the brake hydraulic system Check the operation of the brake light switches Check the headlight aim (see Chapter 8) Check the clutch hydraulic system Check the stand pivots Check the operation of the suspension Check the steering head bearings for play Check the condition of the wheels and tires Check the tightness of all nuts, bolts and fasteners

Every 12,000 miles (19,200 km)


Replace the air filter element (1986 through 1988 Magnas) Check the Evaporative emission control system (1986 through 1988 models) Replace the clutch and brake fluid (or every two years, whichever comes sooner)

Every 24,000 miles (36,000 km)

Replace the coolant
Replace the fuel filter (1982 through 1986 Magnas and 1100 Sabres) Replace the final drive oil



3.2 Rotate the wiper to clear the oil level inspection window (1982 750 models)



3.3 Add engine oil via the plug in the front of the right engine case

2 Introduction to tune-up and routine maintenance

This Chapter covers in detail the checks and procedures necessary for the tune-up and routine maintenance of your motorcycle. Section 1 includes the routine maintenance schedule, which is designed to keep the machine in proper running condition and prevent possible problems. The remaining Sections contain detailed procedures for carrying out the items listed on the maintenance schedule, as well as additional maintenance information designed to increase reliability.

Since routine maintenance plays such an important role in the safe and efficient operation of your motorcycle, it is presented here as a comprehensive check list. For the rider who does all his/her own maintenance, these lists outline the procedures and checks that should be done on a routine basis.

Maintenance information is printed on decals attached to the motorcycle. If the information on the decals differs from that included here, use the information on the decal.

Deciding where to start or plug into the routine maintenance schedule depends on several factors. If you have a motorcycle whose warranty has recently expired, and if it has been maintained according to the warranty standards, you may want to pick up routine maintenance as it coincides with the next mileage or calendar interval. If you have owned the machine for some time but have never performed any maintenance on it, then you may want to start at the nearest interval and include some additional procedures to ensure that nothing important is overlooked. If you have just had a major engine overhaul, then you may want to start the maintenance routine from the beginning. If you have a used machine and have no knowledge of its history or maintenance record, you may desire to combine all the checks into one large service initially and then settle into the maintenance schedule prescribed.

The Sections which outline the inspection and maintenance procedures are written as step-by-step comprehensive guides to the performance of the work. They explain in detail each of the routine inspections and maintenance procedures on the check list. References to additional information in applicable Chapters is also included and should not be overlooked.

Before beginning any maintenance or repair, the machine should be cleaned thoroughly, especially around the oil filter, spark plugs, cylinder head covers, side covers, carburetors, etc. Cleaning will help ensure that dirt does not contaminate the engine and will allow you to detect wear and damage that could otherwise easily go unnoticed.

3 Fluid levels - check

Engine oil

Refer to illustrations 3.2, 3.3 and 3.7

1982 750 models

- 1 Check the oil level with the engine cold. Place the motorcycle on its main stand on level ground.
- 2 Locate the engine oil inspection window on the lower right side of the engine. If necessary, use a screwdriver to rotate the wiper in order to clean the inspection window (see illustration).
- 3 Note where the oil level is in relation to the upper and lower level marks located on either side of the inspection window. The level should be between these two marks. If the oil level is below the lower mark, remove the filler cap and add enough oil of the recommended grade and type to bring the level up to the upper mark (see illustration). Do not overfill. Re-install the filler cap.
- 4 Run the engine and check that the oil pressure warning light goes out after a few seconds.

All other models

- 5 Run the engine for 2 to 3 minutes, then stop it. **Caution:** Do not run the engine in an enclosed space such as a garage or shop. Place the motorcycle on its main stand (have an assistant hold it vertical on 1987 and 1988 700/750 Magna models) on level ground.
- 6 Remove the oil level dipstick from the rear of the engine right cover and wipe its end clean. Re-insert the dipstick, but don't screw it in, then remove it and check the oil level.
- 7 Note where the oil level is in relation to the upper and lower level marks on the dipstick. The level should be between these two marks. If the oil level is below the lower mark, remove the filler cap and add enough oil of the recommended grade and type to bring the level up to the upper mark (see illustration). Do not overfill. Re-install the filler cap.
- 8 Some later 700/750 models retain the oil level inspection window (see Step 2), although the dipstick method is recommended.
- 9 Run the engine and check that the oil pressure warning light goes out after a few seconds.

Brake fluid

Refer to illustration 3.12

- 10 In order to ensure proper operation of the hydraulic disc brakes,



3.7 Oil level should lie between dipstick marks
(all except 1882 750 models)

the fluid level in the master cylinder reservoir(s) must be properly maintained.

Front brake

11 With the motorcycle on the main stand (or held upright), turn the handlebars until the top of the master cylinder is as level as possible. If necessary, tilt the motorcycle to make it level.

12 Look closely at the inspection window in the master cylinder reservoir. Make sure that the fluid level, visible in the sightglass, is above the LOWER mark on the reservoir (see illustration).

13 If the level is low, the fluid must be replenished. Before removing the master cylinder cover, cover the fuel tank to protect it from brake fluid spills (which will damage the paint) and remove all dust and dirt from the area around the cap.

14 Unscrew the retaining screws and lift off the cover, diaphragm plate (where fitted), diaphragm and float (1988 750 Magna model). Using a good quality brake fluid of the recommended type, from a freshly opened container, top up the reservoir to the upper level mark; this mark is in the form of a line, cast on the inside of the front face of the reservoir.

15 When the fluid level is correct, clean and dry the diaphragm, fold it into its compressed state and install it in the reservoir followed by the diaphragm plate. Install the reservoir cover and securely tighten its retaining screws.

Rear brake (1100 models)

16 With the motorcycle on the main stand, remove the right side cover and check the fluid level in the rear brake reservoir. Make sure that the fluid level, visible through the translucent material of the reservoir, is above the LOWER mark on the reservoir.

17 If the level is low, the fluid must be replenished. Remove any dust and dirt from the area around the cap. Unscrew the reservoir cap and remove the diaphragm plate and diaphragm. Using a good quality brake fluid of the recommended type, from a freshly opened container, top up the reservoir to the UPPER level mark.

18 When the fluid level is correct, clean and dry the diaphragm, fold it into its compressed state and install it in the reservoir followed by the diaphragm plate. Install the reservoir cap, tightening it securely, and install the right side cover.

Both brakes

19 Check the operation of both brakes before riding the motorcycle; if there is evidence of air in the system, it must be bled as described in Chapter 7.

20 If the brake fluid level was low, inspect the brake system for leaks.



3.12 Brake/clutch fluid level must be above LOWER mark on master cylinder

Clutch fluid

21 The procedure for checking the clutch fluid is identical to the front brake fluid checking procedure above.

Coolant level

Refer to illustration 3.23

22 Remove the left side cover on 700/750 Sabres, or the right side cover on all other models.

23 Start the engine and allow it to idle until it reaches normal operating temperature. With the engine thoroughly warmed up, the coolant level in the reservoir should be between the Upper and Lower marks on the side of the reservoir (see illustration).

24 If the coolant is below the Lower mark, remove the cap from the reservoir tank and add coolant of the specified type (see Specifications) to bring the level to the Upper mark. **Note:** Be careful not to spill coolant on any painted surfaces, as damage to the paint could occur.

25 Re-install the reservoir cap and the side cover.


26 If the coolant is significantly above the upper level mark at any time, the surplus coolant should be siphoned off to prevent it from being expelled out of the breather hose when the engine is running.

27 If the coolant level falls steadily, check the system for leaks as

1



3.23 Coolant level should lie between UPPER and LOWER lines on reservoir tank



3.29 Final drive unit oil filler cap (A) and drain bolt (B)

described in Section 19. If no leaks are found and the level still continues to fall, it is recommended that the machine be taken to a Honda service agent who will pressure test the system.

Final drive unit oil

Refer to illustration 3.29

28 If the motorcycle has just been ridden, wait ten minutes for the oil to settle before checking the level. Place the motorcycle on its main stand. Be sure it is on level ground.

29 On 1982 and 1983 750 models, remove the oil filler cap (see illustration). Look into the aperture, using a hand-held flashlight if necessary, and locate the step in the casting. Align the top edge of one of the ring gear teeth with the top of the step (rotate the rear wheel to move the ring gear) - at this point the oil should be level with the top of the next tooth down on the ring gear. If the oil level is lower than this, add more oil of the correct type and grade, using a funnel, syringe or pump, to bring it to its proper level.

30 On all other models, remove the oil filler cap (see illustration 3.29). The level of the oil should be just at the lower edge of the oil filler hole. If the oil level is lower than this, add more oil of the correct type and grade, using a funnel, syringe or pump, to bring it to its proper level.

31 On all models, re-install the oil filler cap, tightening it securely.

4 Battery - check

Battery electrolyte


Caution: Take care when working with the battery that you do not allow the electrolyte to contact your eyes, skin or clothing, as it contains sulphuric acid. Flush any contacted area immediately with plenty of water. Any contact with eyes requires prompt medical attention.

Refer to illustration 4.1

1 To check the level of the electrolyte in the battery, remove the right side cover (1982 through 1984 700/750 Magnas, all 700/750 Sabres and all 1100 Magnas) or left side cover (1100 Sabres). On 1985 through 1988 700/750 Magnas, the battery must be lifted out of its holder to check the level (see Chapter 8). The level should be between the Upper and Lower level marks printed on the outside of the battery case (see illustration).

2 If the electrolyte level is at or below the Lower mark, the battery must be removed in order to add more water (see Chapter 8).

3 With the battery removed from the motorcycle, remove each cell cap and add enough distilled water to each cell to bring the level to the



4.1 Battery electrolyte level should lie between level marks on casing



4.6 Measuring electrolyte specific gravity with a hydrometer

Upper mark. Do not overfill. Also, do not use tap water, except in an emergency, as this will shorten the service life of the battery. The cell holes are quite small so it may help to use a plastic squeeze bottle with a small spout to add the water.

4 After filling install the battery and ensure its vent hose is routed correctly (see Chapter 8).

Specific gravity check

Refer to illustration 4.6

5 Remove the battery (see Chapter 8). Check the specific gravity of the electrolyte in each cell using a small hydrometer made especially for motorcycle batteries. These are available from most dealer parts departments.

6 Remove the caps, draw some electrolyte from the first cell into the hydrometer and note the specific gravity (see illustration). Compare the reading to the Specifications listed in this Chapter. Note: Add 0.004 points to the reading for every 10°F above 68°F (20°C) - subtract 0.004 points from the reading for every 10°F below 68°F (20°F). Return the electrolyte to the cell and repeat the check for the remaining cells. When the check is complete, rinse the hydrometer thoroughly with clean water.

7 If the specific gravity of the electrolyte in each cell is as specified, the battery is in good condition and is apparently being charged by the motorcycle's charging system.



5.1 Brake pad wear can be checked through inspection window in caliper body (arrow)



5.4 Drum brake linings are worn when indicator pointer and index mark align

8 If the specific gravity is low, the battery is not fully charged. This may be due to corroded battery terminals, a dirty battery case, a malfunctioning charging system, or loose or corroded wiring connections. On the other hand, it may be that the battery is worn out, especially if the motorcycle is old, or that infrequent use of the motorcycle prevents normal charging from taking place.

9 Be sure to correct any problems and charge the battery if necessary. Refer to Chapter 8 for additional battery maintenance and charging procedures.


10 Install the battery (see Chapter 8).

5 Brake pads/linings - wear check

Disc brake pads

Refer to illustrations 5.1 and 5.2

1 A quick check of the brake pads can be made without removing them from the caliper. Pad wear can be judged by viewing the pad material through the inspection slot indicated by the cast arrow on the caliper body; the use of a hand-held flashlight will aid visibility. The original equipment pads have a cutout between the pad metal backing and the friction material which denotes the wear limit - if the friction material of either pad has worn down to expose the cutout, the pads



5.2 Brake pad wear cutout (upper arrow) and wear grooves (lower arrow)

must be replaced (see illustration).

2 As a further check, view the pads from the caliper mouth. If the friction material has worn down level with the base of the grooves or slots in the pad, the need for replacement is indicated (see illustration). Refer to Chapter 7 for the pad replacement procedure. However, it is recommended that the pads be removed and a more detailed inspection be carried out as described in Sections 2 and 15 of Chapter 7.

3 If it is impossible to check the amount of pad material remaining due to a build-up of road dirt, remove the pads for thorough inspection and cleaning (see Chapter 7).

Drum brake linings (700/750 models)

Refer to illustration 5.4

4 The drum brake shoes are checked by applying the brake fully and checking to see whether the wear indicator pointer on the brake lever aligns with the index mark on the brake panel (see illustration).

5 If it aligns with the index mark or exceeds it, the brake shoes are worn and must be replaced with new ones (see Chapter 7). If in any doubt about the amount of lining material remaining on the shoes, or if brake action is poor, remove the wheel for measurement of the lining thickness (see Chapter 7).

6 Brake system -

checks *Brake checks*

1 A routine general check of the brakes will ensure that any problems are discovered and remedied before the rider's safety is jeopardized.


2 Check the brake lever and pedal for loose connections, excessive play, bends, and other damage. Replace any damaged parts with new ones (see Chapter 7).

3 Make sure all brake fasteners are tight. Check the brake pads/linings for wear (see Section 5) and on disc brake models, make sure the fluid level in the reservoirs is correct (see Section 3).

4 On disc brakes, look for leaks at the hose connections and check for cracks in the hoses. If the lever or pedal is spongy, bleed the brakes as described in Chapter 7. Drain and replace the brake fluid at the specified interval.

Brake lever freeplay (1985 1100 Sabre and 1985/86 1100 Magna)

5 Measure the freeplay at the ball end of the front brake lever. Assuming that there is no air in the hydraulic system, resulting in a



6.8 Brake pedal height adjustment bolt on 700/750 models (arrow)

spongy feel to the lever (see below), the lever should move 20 to 30 mm before the front brake comes on.

6 If outside of this measurement, adjust using the knurled ring at the lever pivot, noting that one of the index marks on the ring must align with the arrow stamped in the top of the lever. Check operation of the front brake and check that there is no brake drag.


Brake pedal height

Refer to illustration 6.8


7 Brake pedal height is important to ensure maximum braking efficiency. Incorrect height can cause brake drag or prevent full application of the rear brake.

8 On 700/750 Sabres and 1982 through 1984 700/750 Magnas, the top of the brake pedal should be 7 mm (0.3 in) below the top of the rider's footpeg. On later 700/750 Magna models, the top of the brake pedal should be 25 mm (1 in) above the top of the rider's footpeg. To adjust, loosen the locknut on the adjusting screw and turn the screw in or out until the pedal height is correct, then tighten the locknut (see illustration).

9 On 1100 Sabre models the top of the brake pedal should be 15 mm (0.6 in) below the top of the footpeg. On 1100 Magna models the top of the brake pedal should be 30 mm (1.2 in) above the top of the rider's footpeg. Make adjustment at the master cylinder pushrod by loosening the locknut on the clevis and rotating the pushrod to alter the pedal height, tighten the locknut on completion.



6.12 Rear brake stop light switch adjuster nut (arrow)



6.10 Adjust brake pedal freeplay using nut at end of brake rod (arrow)

Brake pedal freeplay

Refer to illustration 6.10

10 On 700/750 models, depress the pedal and measure how far it travels before the shoes contact the drum. Compare the results to the Specifications. Adjustment is made by turning the adjusting nut on the brake rod end (see illustration).

Brake stop lights

Refer to illustration 6.12

11 Make sure the brake light operates when the front brake lever is depressed. The front brake light switch is not adjustable. If it fails to operate properly, replace it with a new one (see Chapter 8).

12 Make sure the brake light is activated just before the rear brake pedal takes effect. If adjustment is necessary, hold the switch and turn the adjusting ring on the switch body until the brake light is activated when required (see illustration). If the switch doesn't operate the brake lights, check it as described in Chapter 8.

7 Tires/wheels - general check

Refer to illustrations 7.2 and 7.4

1 Routine tire and wheel checks should be made with the



7.2 Measuring tire tread depth



7.4 Measuring tire air pressure



8.3a With the throttle at rest, mark the relationship of the grip to the right switch assembly ...

realization that your safety depends to a great extent on their condition.


2 Check the tires carefully for cuts, tears, embedded nails or other sharp objects and excessive wear. Operation of the motorcycle with excessively worn tires is extremely hazardous, as traction and handling are directly affected. Measure the tread depth at the center of the tire and replace worn tires with new ones when the tread depth is less than specified (*see illustration*).

3 Repair or replace punctured tires as soon as damage is noted. Do not try to patch a torn tire, as wheel balance and tire reliability may be impaired.

4 Check the tire pressures when the tires are **cold** and keep them properly inflated (*see illustration*). Proper air pressure will increase tire life and provide maximum stability and ride comfort. Keep in mind that low tire pressures may cause the tire to slip on the rim or come off, while high tire pressures will cause abnormal tread wear and unsafe handling.

5 The cast wheels used on this machine are virtually maintenance free, but they should be kept clean and checked periodically for cracks and other damage. Never attempt to repair damaged cast wheels; they must be replaced with new ones.

6 Check the valve rubber for signs of damage or deterioration and have it replaced if necessary. Also, make sure the valve stem cap is in place and tight. If it is missing, install a new one made of metal or hard plastic.



8.3b ... then measure the distance the throttle grip can be rotated before a slight resistance is felt

8 Throttle and choke operation/grip freeplay - check and adjustment

Throttle cables


Refer to illustrations 8.3a, 8.3b, 8.4 and 8.5

1 Make sure the throttle grip rotates easily from fully closed to fully open with the front wheel turned at various angles. The grip should return automatically from fully open to fully closed when released.

2 If the throttle sticks, this is probably due to a cable fault. Remove the cables as described in Chapter 4 and lubricate them as described in Section 15. Install each cable, routing them so they take the smoothest route possible. If this fails to improve the operation of the throttle, the cables must be replaced. Note that in very rare cases the fault could lie in the carburetors rather than the cables, necessitating the removal of the carburetors and inspection of the throttle linkage (*see Chapter 4*).

3 With the throttle operating smoothly, check for a small amount of freeplay at the grip. The amount of freeplay in the throttle cables, measured in terms of twistgrip rotation, should be as given in this Chapter's Specifications (*see illustrations*). If adjustment is necessary, adjust idle speed first (*see Section 17*).

4 Loosen the locknut on the cable upper adjuster and rotate the adjuster until the correct amount of freeplay is obtained, then tighten



8.4 Throttle cable upper adjuster (arrow).



8.5 ... and lower adjuster on carburetors (arrow)



9.4 When bleeding the clutch connect tube to bleed valve as shown

the locknut (see illustration). If it is not possible to obtain the correct freeplay with the upper adjuster, it will also be necessary to make adjustment at the lower adjuster, situated on the carburetors.

5 To gain access to the lower adjuster remove the fuel tank or trig it up on early Magnas (see Chapter 4) (see illustration). Screw the upper cable adjuster in to obtain the maximum possible freeplay, then loosen the lower adjuster locknut and set the cable freeplay using first the lower adjuster and then, if necessary, the upper adjuster. Once the freeplay is correct tighten the locknuts securely.

6 Check that the throttle twistgrip operates smoothly and snaps shut quickly when released. **Warning:** Turn the handlebars all the way through their travel with the engine idling. Idle speed should not change. If it does, the cables may be routed incorrectly. Correct this condition before riding the bike (see Chapter 4).

Choke cable

7 Proper choke operation will ensure fast starts and quick engine warm up. Initially, move the choke lever up and down making sure it moves smoothly.

8 If there is any binding or drag in the lever's operation, the cable should be checked for kinks or damage to the cable casing and then removed (see Chapter 4) and lubricated as described in Section 15.

9 If cable lubrication fails to improve the operation of the choke, the cable must be replaced. Note that in very rare cases the fault could lie in the carburetors rather than the cable, necessitating the removal of the carburetors and inspection of the choke plungers as described in Chapter 4.

10 With the choke mechanism operating smoothly, check the choke cable freeplay as described in Chapter 4.

11 Once the choke mechanism is correctly adjusted, install the air filter housing and fuel tank as described in Chapter 4.

9 Clutch - checks and bleeding

Refer to illustration 9.4

1 Check the clutch lever for loose connections, excessive play, bends, and other damage. Replace any damaged parts with new ones (see Chapter 2).

2 On 1985 1100 Sabres and 1985/86 1100 Magna models, measure the freeplay at the ball end of the clutch lever. Assuming that there is no air in the hydraulic system, resulting in a spongy feel to the lever (see below), the lever should move 20 to 30 mm before the clutch disengages. If outside of this measurement, adjust using the knurled ring at the lever pivot, noting that the index mark on the ring must align with the arrow stamped in the top of the lever. Start the engine and check that the clutch disengages and engages smoothly, without slip or drag.

3 Check that the fluid level in the reservoir is correct (see Section 3). Look for leaks at the hose connections and check for cracks in the hoses.

4 If the lever is spongy, bleed the clutch line of air. The bleeding operation is exactly the same as described for bleeding the brakes in Chapter 7, Section 11. Remove the slave cylinder bleed valve cap, and connect the bleed tube to the valve (see illustration).

10 Engine oil/filter - change

Refer to illustrations 10.4a and 10.4b

1 Consistent routine oil and filter changes are the single most important maintenance procedure you can perform on a motorcycle. The oil not only lubricates the internal parts of the engine, transmission and clutch, but it also acts as a coolant, a cleaner, a sealant, and a protectant. Because of these demands, the oil takes a terrific amount of abuse and should be replaced often with new oil of the recommended grade and type. Saving a little money on the difference in cost between a good oil and a cheap oil won't pay off if the engine is damaged.

2 Before changing the oil and filter, warm up the engine so the oil will drain easily. Be careful when draining the oil, as the exhaust pipes, the engine, and the oil itself can cause severe burns.


3 Put the motorcycle on the main stand (where fitted) and position a clean drain pan below the engine. Unscrew the oil filter cap to vent the crankcase and act as a reminder that there is no oil in the engine.

4 Next, remove the drain plug from the oil pan, as well as the drain plug from the front cylinder head and allow the oil to drain into the pan (on 1987 and 1988 700/750 Magnas hold the motorcycle upright to ensure that the oil drains fully) (see illustrations). Discard the sealing washers on the drain plugs; they should be replaced whenever the plugs are removed.

5 On certain California models, the emission control system canister will prevent access to the oil filter. Disconnect its hoses and remove it from the frame (see Chapter 4). On 1987 and 1988 700/750 Magna models access to the filter is improved if the belly fairing is removed (see Chapter 6). Make sure the drain pan is under the filter, then loosen the oil filter using a strap wrench or the Honda service tool. **Warning:** Take great care not to burn your hands on the exhaust system. Unscrew the filter from the engine unit and empty its contents into the drain pan. If additional maintenance is planned for this time period, check or service another component while the oil is allowed to drain completely.

6 Clean the filter thread and housing on the crankcase with solvent or clean shop towels. Wipe any remaining oil off the filter sealing area of the crankcase.

7 Slip a new sealing washer over the drain plugs. Fit them to the oil



10.4a Engine oil drain plug in oil pan and oil filter (arrows)

pan and front cylinder and tighten to the specified torque setting. Avoid overtightening, as damage will result.


8 Apply a smear of clean oil to the sealing ring of the new filter and screw it into position on the engine. Tighten the filter firmly by hand. If access to the special Honda oil filter tool can be gained, the filter should be tightened to the specified torque setting.

9 Before refilling the engine, check the oil carefully. If the oil was drained into a clean pan, small pieces of metal or other material can be easily detected. If the oil is very metallic colored, then the engine is experiencing wear from break-in (new engine) or from insufficient lubrication. If there are flakes or chips of metal in the oil, then something is drastically wrong internally and the engine will have to be disassembled for inspection and repair.

10 If there are pieces of fiber-like material in the oil, the clutch is experiencing excessive wear and should be checked.

11 If inspection of the oil turns up nothing unusual, refill the crankcase to the proper level with the recommended type and amount of oil and install the filler cap. Start the engine and let it run for two or three minutes. Shut it off, wait a few minutes, then check the oil level. If necessary, add more oil to bring the level up to the upper mark. Check around the drain plugs and filter for leaks.

12 The old oil drained from the engine cannot be re-used and should be disposed of properly. Check with your local refuse disposal company, disposal facility or environmental agency to see whether they will accept the used oil for recycling. Don't pour used oil into drains or onto the ground. After the oil has cooled, it can be drained into a suitable container (capped plastic jugs, topped bottles, milk cartons, etc.) for transport to one of these disposal sites.



10.4b Engine oil drain plug in front cylinder bank

11 Final drive unit - oil change

1 Place the motorcycle on its stand, and position a drain tray beneath the drain plug in the base of the final drive unit. Remove the plug and allow the oil to drain - allow 10 minutes or so for the oil to drain fully, then install the drain plug and tighten it securely (see illustration 3.29).

2 Remove the large oil filler cap from the rear of the unit, and fill with the specified type and quantity of oil. Wait a few minutes for the oil level to settle then check it as described in Section 3, adjusting the level accordingly. Install the oil filler cap.

12 Air filter element - cleaning and replacement

1982 750 Sabre

Refer to illustrations 12.1 and 12.3

1 Pry out the plastic caps that cover the air cleaner cover screws. Do this on both the left and right air cleaners (see illustration).

2 Remove the cover screws and lift off the covers. Recover their sealing rings.


3 Remove the nuts and washers that retain the air filter elements and lift them out. Remove the plastic frames from inside of the foam elements (see illustration).

4 Wash each element thoroughly in clean solvent, then dry it with clean rags. Wipe out the housings with a clean rag.

1



12.1 Pry out caps to reveal air filter cover screws on 1982 Sabre



12.3 Separate element from frame for cleaning on 1982 Sabre

5 Soak the clean elements in SAE 80-90 gear oil, then squeeze out as much of the oil as possible (do not wring the element). Hang the elements up and allow any excess oil to drip out - they must not be saturated with oil.

6 Install the filters by reversing the removal steps. Ensure the cover sealing rings are in place and apply a light smear of grease to them.

1983-on 700/750 and all 1100 Sabre models


7 Remove the fuel tank (see Chapter 4).

8 Remove the two air filter cover screws, lift off the cover with its sealing ring and lift out the element together with its support frames. Separate the support frames from the element.

9 Wash the element thoroughly in clean solvent, then dry it with clean rags. Wipe out the housing with a clean rag.

10 Soak the clean element in SAE 80-90 gear oil, then squeeze out as much of the oil as possible (do not wring the element). Hang the element up and allow any excess oil to drip out - it must not be saturated with oil.

11 Install the filter by reversing the removal steps. Ensure the cover sealing ring is in place and apply a light smear of grease to it.



Magna models

Refer to illustration 12.14

12 Remove the fuel tank (see Chapter 4); on 1100 models and early 700/750 models, it can be raised on its support rod if less than half full.

13 On 1985 through 1988 700/750 models, release their retaining screws and remove the plastic covers from each side of the frame deadstock. On 1985/86 700 models remove the fresh air intake cover from the front of the air filter.

14 Remove the air cleaner cover screws, lift off the cover and its sealing ring (see illustration). Lift out the paper filter and tap it on a solid surface to dislodge any dirt and dust.

15 If compressed air is available, use it to remove dirt and dust from the element by blowing from the inside outwards. Wipe out the housing with a clean rag.

16 Replace the paper element with a new one at the required intervals, regardless of its apparent condition.

17 Install the new filter by reversing the removal steps. Ensure the cover sealing ring is in place and apply a smear of grease to it. If removed, install the fuel tank as described in Chapter 4.

12.14 Remove air cleaner cover (1) screws (2) to access element (3) on Magna models

13 Cylinder compression - check

1 Among other things, poor engine performance may be caused by leaking valves, incorrect valve clearances, a leaking head gasket, or worn pistons, rings and/or cylinder walls. A cylinder compression check will help pinpoint these conditions and can also indicate the presence of excessive carbon deposits in the cylinder heads.

2 The only tools required are a compression gauge and a spark plug wrench. Depending on the outcome of the initial test, a squirt-type oil can may also be needed.

3 Start the engine and allow it to reach normal operating temperature, then stop it.

4 Place the motorcycle on its stand.

5 Remove the spark plugs as described in Section 14. **Caution:** Work carefully - don't strip the spark plug hole threads and don't burn your hands on the hot cylinder head.

6 Disable the ignition by switching the kill switch to OFF.

7 Install the compression gauge in one of the spark plug holes and place a rag over the other three plug holes as a precaution against fire risk.

8 Hold the throttle wide open and crank the engine over a minimum of four or five revolutions (or until the gauge reading stops increasing) and observe the initial movement of the compression gauge needle as well as the final total gauge reading. Repeat the procedure for the other cylinders and compare the results to the value listed in this Chapter's Specifications.


9 If the compression in all four cylinders built up quickly and evenly

to the specified amount, you can assume the engine upper end is in reasonably good mechanical condition. Worn or sticking piston rings and worn cylinders will produce very little initial movement of the gauge needle, but compression will tend to build up gradually as the engine spins over. Valve and valve seat leakage, or head gasket leakage, is indicated by low initial compression which does not tend to build up.

10 To further confirm your findings, add a small amount of engine oil to each cylinder by inserting the nozzle of a squirt-type oil can through the spark plug holes. The oil will tend to seal the piston rings if they are leaking. Repeat the test for the other cylinders.

11 If the compression increases significantly after the addition of the oil, the piston rings and/or cylinders are definitely worn. If the compression does not increase, the pressure is leaking past the valves or the head gasket. Leakage past the valves may be due to insufficient valve clearances, burned, warped or cracked valves or valve seats, or valves that are hanging up in the guides.

12 If the compression readings are considerably higher than specified, the combustion chambers are probably coated with excessive carbon deposits. It is possible (but not very likely) for carbon deposits to raise the compression enough to compensate for the effects of leakage past rings or valves. Use of a fuel additive that will dissolve the adhesive bonding the carbon particles to the crown and chamber is the easiest way to remove the build-up. Otherwise, the cylinder head(s) will have to be removed and decarbonized (Chapter 2).



14.2 Use the correct size tool when removing spark plugs



14.6a Using a wire type gauge to measure the spark plug gap

14 Spark plugs - check and replacement

Refer to illustrations 14.2, 14.6a and 14.6b

1 All models are equipped with spark plugs which have 12 mm threads and an 18 mm hex. Make sure that your spark plug wrench or socket is the correct size before attempting to remove the plugs.

2 Disconnect the spark plug caps from the spark plugs. If available, use compressed air to blow any accumulated debris from around the spark plugs. Remove the plugs and lay them out in relation to their cylinder number; if any plug shows up a problem it will then be easy to identify the troublesome cylinder (see illustration).

3 Inspect the electrodes for wear. Both the center and side electrodes should have square edges and the side electrode should be of uniform thickness. Look for excessive deposits and evidence of a cracked or chipped insulator around the center electrode. Compare your spark plugs to the color spark plug reading chart. Check the threads, the washer and the ceramic insulator body for cracks and other damage.


4 If the electrodes are not excessively worn, and if the deposits can be easily removed with a wire brush, the plugs can be regapped and re-used (if no cracks or chips are visible in the insulator). If in doubt concerning the condition of the plugs, replace them with new ones, as the expense is minimal.

5 Cleaning spark plugs by sandblasting is permitted, provided you clean the plugs with a high flash-point solvent afterwards.

6 Before installing new plugs, make sure they are the correct type and heat range. Check the gap between the electrodes, as they are not preset. For best results, use a wire-type gauge rather than a flat (feeler) gauge to check the gap. If the gap must be adjusted, bend the side electrode only and be very careful not to chip or crack the insulator nose (see illustrations). Make sure the washer is in place before installing each plug.

7 Since the cylinder head is made of aluminum, which is soft and easily damaged, thread the plugs into the heads by hand. Since the plugs are recessed, slip a short length of hose over the end of the plug to use as a tool to thread it into place. The hose will grip the plug well enough to turn it, but will start to slip if the plug begins to cross-thread in the hole - this will prevent damaged threads and the resultant repair costs.

8 Once the plugs are finger-tight, the job can be finished with a socket. If a torque wrench is available, tighten the spark plugs to the specified torque listed in this Chapter's Specifications. If you do not have a torque wrench, tighten the plugs finger-tight (until the washers bottom out on the cylinder head) then use a wrench to tighten them an



14.6b Bend the side electrode only to adjust spark plug gap


additional 1/4 turn. Regardless of the method used, do not over-tighten them. 9 Reconnect the spark plug caps.

15 Lubrication - general

Refer to illustration 15.3

1 Since the controls, cables and various other components of a motorcycle are exposed to the elements, they should be lubricated periodically to ensure safe and trouble-free operation.

2 The footpegs, clutch and brake lever, brake pedal, shift lever and side and main stand pivots should be lubricated frequently. In order for the lubricant to be applied where it will do the most good, the component should be disassembled. However, if chain and cable lubricant is being used, it can be applied to the pivot joint gaps and will usually work its way into the areas where friction occurs. If motor oil or light grease is being used, apply it sparingly as it may attract dirt (which could cause the controls to bind or wear at an accelerated rate). **Note:** One of the best lubricants for the control lever pivots is a dry-film lubricant (available from many sources by different names).



15.3 Lubricating a cable with a pressure lube adapter (make sure the tool seats around the inner cable)

3 To lubricate the cables, disconnect the relevant cable at its upper end, then lubricate the cable with a pressure lube adapter (see illustration). See Chapter 4 for the choke and throttle cable removal procedures, and Chapter 2 for clutch cable removal details.

4 The speedometer cable should be removed from its housing and lubricated with motor oil or cable lubricant. Do not lubricate the upper few inches of the cable as the lubricant may travel up into the speedometer head.

16 Valve clearances - check and adjustment


1 The engine must be completely cool for this maintenance procedure, so let the machine sit overnight before beginning.

2 Place the motorcycle on its stand. Remove the fuel tank (see Chapter 4). Remove the side covers (see Chapter 6).

All models except 1986 through 1988 700/750 Magna

Refer to illustrations 16.6, 16.8 and 16.9

3 Drain the coolant (see Section 20) and remove the radiator (See Chapter 3). On the 1986 1100 Magna model it is possible to shut off the tap at the radiator bottom hose union, having released coolant pressure by momentarily loosening the coolant drain plug set in the



16.6 Align TDC mark with crankcase rear joint when checking valve clearances (mark for cylinders 1 and 3 shown)

subframe, disconnect the radiator side mountings and wiring, disconnect the top and bottom hoses and pivot the radiator forwards about its top mounting point, tie it to the forks out of the way of the front cylinder (see Section 20).

4 Remove all four spark plugs.

5 Remove the valve cover bolts and lift off both valve covers, plus the rear cylinder valve cover base (see Chapter 2).

6 Remove the alternator cover from the left side of the engine. Note that oil will run from the cover so have a drain tray positioned to catch the oil. Wipe any oil off the alternator rotor. Rotate the crankshaft end bolt clockwise until the T1.3 mark on the rotor aligns exactly with the casing rear joint (see illustration).


7 With the T1.3 mark positioned as described, the rear cylinders are at TDC. Check whether cylinder No 1 is on compression (all four valves closed) and if not, rotate the crankshaft one full turn to realign the T1.3 mark. Carry out the valve clearance check on No 1 cylinder's valves.

8 Using two feeler blades of the correct thickness (see Specifications), insert them between each valve stem end and its adjuster screw tip of the rocker and check that they are a firm sliding fit (see illustration). **Note:** It is important that two feeler blades are used to prevent twisting of the rocker arm and subsequently incorrect readings.

9 If the feeler blades are not a firm sliding fit, loosen the locknut on the adjusting screws and turn the adjusting screw in or out to obtain the correct clearance. Hold the adjuster screw still screw while the locknut is tightened, then recheck the clearance to ensure that it has



16.8 Measuring the valve clearances (both valves should be checked at the same time)



16.9 Adjusting the valve clearances