

BORDER GUARD TRAINING CENTRE

TECHNICAL DOCUMENTATION UNIT OPERATING & MAINTENANCE DATA MODULE

Glock 17 – Shooting Training and Maintenance Procedures

DM Code: *A-00-17-0001-00A-040A-A*

Model: Glock 17

Applicability: Border Guard Officers – Training & Armory Procedures

Author: Aleksandra – Technical Writer / Instructional Designer

Language: English

1. Identification and Status Section (ISS)

Title: Glock 17 – Shooting Training Procedure and Full Disassembly

Purpose: To provide standardized instructions for safe handling, shooting, field stripping, and full maintenance of the Glock 17 pistol.

Status: Training / Non-classified Skill

Level: Basic (Shooting), Intermediate (Field Strip), Advanced (Full Disassembly)

Safety Classification: Contains mandatory safety warnings.

2. Introduction

This data module provides procedures for:

- Safe handling of the Glock 17
- Preparing the weapon for shooting
- Conducting live-fire training
- Field stripping for routine cleaning
- Full disassembly for maintenance and inspection
- Reassembly and function checks

These procedures are intended for Border Guard officers undergoing firearms training or performing armory maintenance.

3.1 General Firearm Safety Rules (Mandatory)

WARNING – LETHAL WEAPON: Failure to follow these rules may result in serious injury or death.

1. Treat every firearm as if it is loaded.
2. Never point the muzzle at anything you do not intend to shoot.
3. Keep your finger off the trigger until ready to fire.
4. Be sure of your target and what is beyond it.

3.2 Range Safety Protocols

- Wear ballistic-rated eye and hearing protection.
- Follow all instructions from the firearms instructor.
- Use only authorized service ammunition.
- Handle firearms only in designated shooting zones.
- Report any malfunction, misfire, or unsafe behavior immediately.

3.3 Maintenance Safety

WARNING – BEFORE DISASSEMBLY:

- Remove magazine.
- Lock slide open.
- Visually and physically inspect chamber.
- Point firearm in a safe direction.
- Wear eye protection.

4. Tools, Equipment, and Materials

4.1 Required for Shooting Training

- Glock 17 pistol
- Approved 9mm ammunition
- Eye and ear protection
- Target system
- Cleaning kit (post-training)

4.2 Required for Full Disassembly

- 3/32" punch
- Small pick
- Cleaning solvents and brushes
- Lubricant
- Armorer's mat

5. Procedures

5.1 Preparing the Glock 17 for Shooting

5.1.1 Initial Inspection

1. Remove magazine.
2. Lock slide open.
3. Visually and physically inspect chamber.
4. Inspect barrel for obstructions or damage.
5. Verify magazine condition and cleanliness.

5.1.2 Loading Procedure

1. Load magazine (max 17 rounds).
2. Insert magazine until locked.
3. Pull slide fully rearward and release to chamber a round.
4. Maintain muzzle discipline.

5.2 Shooting Procedure

5.2.1 Stance and Grip

- Assume stable stance (isosceles or modified Weaver).
- Grip pistol firmly with both hands.
- Align sights on target.

5.2.2 Firing

1. Place finger on trigger only when ready.
2. Apply smooth, controlled pressure.
3. Reassess grip and stance after each shot.
4. Fire according to training directives (single shot, controlled pairs, etc.).

5.2.3 Post-Firing Actions

1. Remove finger from trigger.
2. Engage slide lock if required.
3. Remove magazine.
4. Lock slide open and verify empty chamber.

6. Maintenance Procedures

6.1 Field Stripping (Basic Disassembly)

For routine cleaning.

1. Ensure firearm is unloaded.
2. Point in safe direction and pull trigger.
3. Pull slide back ~3 mm.
4. Depress slide lock levers.
5. Remove slide forward off frame.
6. Remove recoil spring assembly.
7. Remove barrel.

6.2 Full Slide Disassembly

Recommended every 6 months or after heavy use.

Tools: 3/32" punch, small pick

1. Depress striker sleeve and remove end plate.
2. Remove striker assembly.
3. Remove extractor depressor plunger and spring.
4. Depress firing pin safety plunger and remove extractor.
5. Remove safety plunger.

Cleaning Note: Clean striker channel thoroughly to prevent light primer strikes.

6.3 Frame Disassembly

1. Remove pins in order:
 - A. Locking block pin
 - B. Trigger pin
 - C. Trigger housing pin
2. Remove slide release lever.
3. Remove locking block.
4. Remove trigger assembly.
5. Optional:
6. Remove slide lock spring and lever
7. Remove magazine release

7. Reassembly Procedure

7.1 Frame Reassembly

1. Install magazine release and spring.
2. Install slide lock lever.
3. Reinstall trigger assembly and locking block.
4. Insert pins in order:
 - Locking block pin
 - Slide release lever
 - Trigger pin
 - Housing pin

7.2 Slide Reassembly

1. Insert firing pin safety plunger.
2. Install extractor.
3. Insert extractor depressor plunger and spring.
4. Insert striker assembly.
5. Install end plate while depressing components.

8. Function Check

1. Rack slide.
2. Pull trigger (dry fire).
3. Hold trigger, rack slide again.
4. Release trigger slowly to confirm reset.
5. Verify striker safety: firing pin must not protrude unless plunger is depressed.

9. Close-Out

- Document maintenance in armory log.
- Return weapon to secure storage.
- Report any irregularities to armorer.