

Startup Guide & Status Overview

Turn on the expansion board and wait for approximately 1 minute. When LED1 on the expansion board lights up blue and the buzzer emits a "beep" sound, it indicates that the ROS configuration is complete and the device has successfully started.

Once the robot has fully powered on, LED2 will blink once every second, and a Wi-Fi hotspot prefixed with "HW" will be broadcast.

The default network mode is AP (Access Point) direct connection. When connecting via the mobile app or remote desktop, use the password: hiwonder. You can now refer to the table below to verify the device status.

Module	Check Steps	Outcome
Expansion Board LEDs	Observe the status of the LEDs	Default AP (Access Point) mode: LED1 is steady on; LED2 blinks once per second.
Buzzer	Listen for a beep sound	A single beep indicates that the expansion board's onboard hardware is functioning normally.
Lidar	Observe for rotation a few seconds after power-on.	The lidar begins to rotate, indicating normal startup.
Depth Camera / Monocular Camera	1) Open the mobile app and connect to the robot. 2) Navigate to the " Robot Control " interface to	The live video feed is displayed, and the pan-tilt mechanism responds to screen gestures (monocular only).

	view the live camera feed. 3) Drag the screen to adjust the camera pan-tilt angle (monocular version only).	
Encoder Motors + STM32 Controller	After powering on, use the wireless controller or the app's "Robot Control" function to operate the robot.	After powering on, use the wireless controller or the app's "Robot Control" function to operate the robot.

Note:

- 1) If the buzzer does not emit a beep, the onboard hardware—such as the IMU or buzzer—may be malfunctioning. This issue is rare under normal use. If it occurs, please contact our support team at support@hiwonder.com.
- 2) If the device's Wi-Fi hotspot is not visible, check whether LED1 on the expansion board is steadily lit and LED2 is flashing once per second.