

Wireless Controller Control

1. Usage Guideline

- ① Before powering on the device, please ensure that the wireless handle receiver is properly plugged in. The USB receiver is pre-installed in the robot during assembly.
- ② When inserting the batteries, make sure to align the positive and negative terminals correctly.



- ③ Each time the robot is powered on, the app's auto-start service will launch automatically. This service includes handle control functionality. If it has not been disabled, no additional setup is required—once the wireless handle is connected, you can start controlling the robot directly.
- ④ Due to the interactive nature of the wireless handle, we do not recommend using this function when multiple robots are operating in the same area. This helps avoid accidental connections and control conflicts.
- ⑤ After turning on the wireless handle, if it is not connected to the robot within 30 seconds, or if there is no activity for 5 minutes after connection, the handle will automatically enter sleep mode. To wake it up, press the "START" button.

2. Device Connection

- 1) After the robot is powered on, turn on the wireless handle. Both the red and green LEDs on the handle will begin flashing simultaneously.
- 2) Wait a few seconds for the handle and robot to pair automatically. Once pairing is successful, the green LED will stay on, and the red LED will turn off.



3. Button Instruction

The following table outlines the functions of the wireless controller's buttons and joysticks (based on the robot's first-person perspective):

Note: 1. Slightly tilting the joystick in any direction allows for low-speed movement.
 2. For the Ackermann chassis, press MODE and START at the same time to switch modes. The buzzer will beep once.

Button	Function	Instruction
START	Stop and restore the robot's body	Short press
Left Joystick - Up	Move forward	Push
Left Joystick - Down	Move backward	Push
Left Joystick - Left	Strafe left (<i>Mecanum chassis only</i>)	Push
Left Joystick - Right	Strafe right (<i>Mecanum chassis</i>	Push

	<i>only)</i>	
Right Joystick - Left	Turn left (<i>Ackermann chassis only)</i>	Push
Right Joystick - Right	Turn right (<i>Ackermann chassis only)</i>	Push