

Web Real-time Monitoring

1. Web Real-time Monitoring

After obtaining the camera information, the live camera feed can be transmitted to the local area network. The real-time monitoring can be achieved by viewing the robot's live feedback images through the webpage.

2. Enable Robot Auto-start Service

Robot's Camera Transmission Service:

1) If the robot has not started up yet, switch it on. Then, you can ahead to the section “2.1 Access Live Camera Feed Through Web” to view the live camera feed through the browser.

2) If the robot has already started up, please follow the steps below:

① Start MentorPi and connect it to the VNC.

② Click  to open the command line terminal.

③ Enter the command. Press “Enter” to start the robot's auto-start service.

When the buzzer sounds a beep, the service restarts successfully.

```
sudo systemctl restart start_node.service
```

```
└─ sudo systemctl restart start_node.service
```

④ Then, you can proceed to “2.1 Access Live Camera Feed Through Web” to view the live camera feed through the browser.

2.1 Access Live Camera Feed Through Web

1) Open any web browser, and input the IP address "http://192.168.149.1:8080/", then hit “Enter”.

Note: if the prompt ‘This site can’t be reached’ occurs, please restart the app auto-start service.

2) Click-on “image_raw(Snapshot)” to access the live camera feed. The

program currently only supports viewing RGB images.

Available ROS Image Topics:

- /depth_cam/depth/
 - [image_raw](#) (Snapshot)
- /depth_cam/ir/
 - [image_raw](#) (Snapshot)
- /depth_cam/rgb/
 - [image_raw](#) (Snapshot)
- /ar_app/image_result (Snapshot)
- /line_following/image_result (Snapshot)

