Device Control Panel

Zero Reading of Ch1 → Select Device

Up, Down, Stop, Fast Up, Fast Down

Read Ch1 → Load (N) — Enter Text

Target/Stop buttons

Target / Stop / Zero — 0

Ramp/Stop buttons

Read Ch2 → Displacement (mm) — Enter Text

Ramp / Stop / Zero — 0 mm/min

Setpoint Values

Unit is loaded by default instrument calibrated unit

| No | Description | Send Read Command | Receive Read Answer |
|----|-------------|-------------------|---------------------|
| 1 | Up | 02 04 09 LRC | 02 04 09 LRC |
| 2 | Fast Up | 02 04 08 LRC | 02 04 08 LRC |
| 4 | Stop | 02 04 04 LRC | 02 04 04 LRC |
| 4 | Down | 02 04 11 LRC | 02 04 11 LRC |
| 5 | Fast Down | 02 04 10 LRC | 02 04 10 LRC |
| 6 | Target Set Point | 02 08 06 D0 D1 D2 D3 LRC | 02 08 06 D0 D1 D2 D3 LRC |
| 7 | Run Target | 02 04 03 LRC | 02 04 03 LRC |
| 8 | Ramp Set Point | 02 08 07 D0 D1 D2 D3 LRC | 02 08 07 D0 D1 D2 D3 LRC |
| 9 | Run Ramp | 02 04 05 LRC | 02 04 05 LRC |
| 10 | Read Channel 1&2 | 02 04 34 LRC | 02 14 34 Data LRC |
| 12 | Zero Channel 1 | 02 05 32 0 LRC | 02 05 32 0 LRC |
| 13 | Zero Channel 2 | 02 05 32 1 LRC | 02 05 32 0 LRC |