

MCC-3 BUCKET 4B - CONVEYOR CV-104 MOTOR STARTER

Supply: 480V 3PH 60Hz from MCC-3 main bus

Breaker: CB-104, 40A thermal-magnetic

Drive: VFD-104 (see OEM manual for fault codes)

Overload: OL-104 set at 32A

Motor: M-104, 25 HP, 480V, FLA 31A

CONTROL CIRCUIT (120V from CPT-3):

Start permissives (all required):

- E-stop string ES-1 healthy
- Upstream conveyor CV-103 running (permissive relay CR-103)
- Belt drift switches DS-104A / DS-104B not tripped
- Pull-cord switches PC-104 (1-4) reset

INTERLOCKS:

- CV-104 trips if downstream conveyor CV-105 stops (interlock relay CR-105)
- Zero-speed switch ZS-104 alarms after 5s below setpoint

NOTES:

1. All work on MCC-3 requires isolation at CB-104 and bus verification.
2. Refer to site procedure SOP-ELEC-07 before opening any bucket.