

Section 6: Fault Codes and Corrective Actions

FAULT CODE TABLE:

F0A1 Overvoltage - DC bus above limit. Check supply, decel time.

F0B2 Undervoltage - DC bus below limit. Check supply, loose terminals.

F0C1 Overcurrent - Output current exceeded 200% of drive rating.

F0D3 Overtemperature - Heatsink above limit. Check fans and filters.

F0E4 Ground fault - Leakage current detected. Megger motor and cable.

F0C1 OVERCURRENT - DETAILS:

Possible causes:

1. Mechanical jam or blockage on the driven load
2. Motor overload (excessive material load, belt drag)
3. Short circuit in motor cable or terminal box
4. Loose power wiring at drive output or motor terminals
5. Failed motor bearing causing mechanical drag
6. Acceleration time set too short for load inertia

Corrective actions:

- Inspect the driven equipment for jams before resetting
- Verify motor current against nameplate FLA
- Check output wiring and motor terminal tightness
- Review acceleration/deceleration parameters (P2.03 / P2.04)

WARNING: Do not reset the drive repeatedly after F0C1.

Repeated resets into a fault can damage the drive and motor.

If the fault returns after one reset, isolate and investigate.