



Outdoor Electrical Safety

A safe outdoor environment... with responsible electrical use

"Using electricity outdoors requires extra precautions because of humidity and water"



Why Do We Care About Outdoor Electrical Safety?

Risks increase because of water, humidity, and the movement of people



Preventing shock

the biggest danger with water



Reducing fires

from poor connections



Protecting children

and the family in the garden



Protecting workers

on farms and in gardens



Protecting devices

and electrical equipment



Safe behavior

in open areas

Remember: Outdoor electricity needs suitable equipment and constant monitoring



Key Outdoor Electrical Risks

They appear due to improper use



**Wiring not
rated for
outdoor use**



**Exposed or
damaged wires**



**Electricity
contacting
water**



**Wires in
walkways**



**Overloading
the sockets**



Use during rain



**Getting close
to power lines**

Message: An outdoor electrical hazard may not be obvious until an injury occurs



Using Outdoor Wiring Safely

It must be rated and suitable for the surrounding conditions



**Certified
outdoor wiring**



**Inspect before
use**



**Don't use
damaged wires**



**Keep it away
from water and
humidity**



**Don't run it
across
walkways**



**Don't run it
under carpets**



**Unplug it after
use**

Remember: A temporary extension must not become a permanent solution

Electricity and Water Outdoors

Their combination increases the risk of electric shock

Use equipment suitable for outdoors

5

Stop use when it gets wet

6

Call a specialist when there is danger

7

Cut the power when in doubt

8

Don't use devices with wet hands

1

Don't run them while it's raining

2

Keep sockets away from water

3

Don't place wiring near irrigation

4

Important Message: Water and electricity don't mix in a safe environment



Safety When Using Outdoor Devices

Gardening tools, lighting, pumps, camping devices



**Read the
manufacturer's
instructions**



**Use them only
in their
intended
location**



**Don't use
indoor ones
outdoors**



**Inspect the
device before
use**



**Don't leave
them
unattended**



**Keep them
away from
children**



**Unplug it after
use**

Remember: Every electrical device has a suitable use environment that must be followed



Safety in Gardens and on Farms

Irrigation systems, electrical equipment, and outdoor worksites



Keep wiring away from irrigation

1

Don't use on wet ground

2

Cut the power before maintenance

3

Don't leave wires in walkways

4

Tools suitable for the outdoor environment

5

Make sure the lighting is secured

6

Inform a specialist of any fault

7

Message: Safe outdoor work starts by separating electricity from water sources

Safety During Camping and Trips

Generators, lighting, chargers, and temporary connections

- | | | | |
|-----------------------------------|---|-----------------------------------|---|
| Always monitor the devices | 5 | Use safe power sources | 1 |
| Unplug before sleeping or leaving | 6 | No connections near seating areas | 2 |
| Keep a fire extinguisher | 7 | Keep devices away from tents | 3 |
| Report any fault immediately | 8 | No generators inside tents | 4 |

Remember: Temporary connections at campsites need more caution than at home



Power Lines and Poles

Getting close to them can pose a major danger



**Don't get close
to power lines**



**Don't touch
any fallen wire**



**Don't raise
long tools near
them**



**Don't climb the
poles**



**Keep children
away from
transformers**



**Report any
fallen wire**



**Follow the
authorities'
instructions**

Message to Employees: A fallen wire is dangerous until specialists prove otherwise

Electricity During Bad Weather

Rain and wind increase outdoor risks



Unplug devices during storms



No devices during rain



Don't touch wet boxes



Keep connections away from water



Secure outdoor devices firmly



Report any fallen wire

Message: Bad weather can turn safe connections into a hazard

Protecting Children Outdoors

Children are drawn to wires and devices without realizing the danger



Young children

Drawn to wires and devices



Children in parks

Touching wiring and sockets



Playing near pools

Pooling water and electricity



Children on farms

Presence of electrical equipment



Children on trips

Temporary devices and generators



Children during holidays

Outdoor decorative lighting

Message: Protection starts by keeping the danger away from the child, not just by warning



What Do You Do When You Notice an Outdoor Electrical Hazard?

Avoid approaching or trying to fix it



Move away from the source of danger



Don't touch the damaged wires



Move others away from the site



Don't try to fix it yourself



Inform the relevant authority



Call 999 in case of danger



Wait for the specialists to intervene



Document the site safely

Remember: Safety starts with not approaching the electrical hazard



Special Cases in Outdoor Electricity

Some situations call for extra caution



**Decorative
lighting during
holidays**



**Outdoor
surveillance
cameras**



**Outdoor
heaters**



**Yard air
conditioners**



Electric gates



**Smart
irrigation
systems**



**Swimming
pools and
gardens**

Important Message: Every outdoor electrical installation needs regular maintenance and inspection



Communication and Reporting an Electrical Hazard

A clear report speeds up the arrival of help



Example of a clear report:

"There is a fallen electrical wire in an open area beside the park, and I have moved people away"



State the
location
precisely



Mention the
type of danger



Report the
injured



Avoid spreading
unconfirmed
information

Remember: An accurate report saves lives and speeds up the arrival of help

Do's and Don'ts in Outdoor Electrical Safety

Correct Practices and Others to Avoid

Don't ×

Don't use indoor devices outdoors

1

Don't touch devices with wet hands

2

Don't run wires across walkways

3

Don't use them during rain

4

Don't approach fallen wires

5

Don't try to fix it yourself

6

Don't leave wiring unattended

7

Do ✓

Use outdoor-rated wiring only

1

Inspect the wires before use

2

Keep electricity away from water

3

Unplug devices after use

4

Report damaged wires

5

Follow the specialists' instructions

6

Call 999 when needed

7



Interactive Scenarios

Practical Application of What You've Learned

Scenario 2 An electrical wire fell in an outdoor area

Correct Action: Don't approach it, move others away, and inform the relevant authority immediately

Scenario 1 An electrical connection near pooling water in the garden

Correct Action: Move away from the site, and inform the person in charge or a specialist to remove the danger

Scenario 4 Rain started while outdoor devices were running

Correct Action: Stop use safely, and move away from the wet connections

Scenario 3 Someone wants to use an indoor device in the garden

Correct Action: It must not be used; an outdoor-rated device should be chosen

Test Your Knowledge

Quick Questions to Assess Your Understanding

Q1: Is it allowed to use an indoor device outdoors?

Answer: No, you must use devices rated for outdoor use



Q2: What do you do if you see a fallen electrical wire?

Answer: I move away from it, move others away, and inform the relevant authority immediately



Q3: Why should connections be kept away from water?

Answer: To reduce the risk of electric shock



Q4: Is it allowed to use outdoor devices during rain?

Answer: No, because humidity and water increase the electrical risk



Q5: What do you do when you notice damaged wiring?

Answer: I stop using it and inform the specialist or person in charge





Thank You

Outdoor electrical safety is everyone's responsibility

Outdoor-rated wiring • Away from water • No rain • No fallen wires • Unplug after use • 999

"Safe use of electricity outdoors protects lives and property"