

■ CUSTOMIZED BODY ELECTRONICS SYSTEM

An intelligent tester II can be used to customize the system settings.

System	Display Content	Contents	Default Setting	Available Setting
Wireless Door Lock	Wireless Control	ON/OFF of the wireless door lock function.	ON	ON/OFF
	Hazard Answer back	ON/OFF of the hazard answer back of the wireless door lock function.	ON	ON/OFF
	Open Door Warning	Function to make the buzzer sound for 10 seconds if the door is open when locking with the wireless door lock function.	ON/ OFF*1	ON/OFF*1
	Unlock 2 Operation	Function to unlock the driver's door by pressing the unlock button of the transmitter once and to unlock all the doors by pressing it twice. In the OFF setting, pressing one time makes all the doors unlocked.	OFF	ON/OFF
	Auto Lock Time	To change the time until re-locking after unlocking with the wireless door lock function.	30 s	30 s / 60 s / 120 s
Door Lock	Unlock Key Twice	Function to unlock only the driver's door by doing the key operation once and to unlock all the doors by doing it twice. In the OFF setting, operating the key "UNLOCK" once makes all the doors unlocked.	OFF	ON/OFF
Power Window*2	Door Key P/W Up	Function to make all the door windows up manually by holding the driver's side door key to the lock side for 1.5 seconds when power source is OFF.	ON/OFF	ON/OFF
	Door Key P/W Down	Function to make all the door windows down manually by holding the driver's side door key to the unlock side for 1.5 seconds when power source is OFF.	ON/OFF	ON/OFF
	P/W Down W/Transmit	Function to make all the door windows down manually by pressing on the transmitter unlock button for 2.4 seconds when power source is OFF.	ON/OFF	ON/OFF
	P/W Up W/Transmit	Function to make all the door windows up manually by pressing on the transmitter lock button for 2.4 seconds when power source is OFF.	ON/OFF	ON/OFF
	P/W Up W/Smart	Function to make all the door windows up manually by pressing on the smart lock button for 3 seconds when power source is OFF.	ON/OFF	ON/OFF

(Continued)

System	Display Content	Contents	Default Setting	Available Setting
Illuminated Entry	Lighting Time	To change the lighting time after closing the door. (It will quickly fade out in case of turning the power source is ON.)	15 s	7.5 s / 15 s / 30 s
	I/L when ACC OFF	Function to switch on Room Light when the power source is operated from “ACC” to “OFF”.	ON	ON/OFF
	I/L ON W/Door Unlock	Function to switch on Room Light when unlocking with the door key cylinder.	ON	ON/OFF
	Room Light when Aprchd	Function to switch on Room Light when the owner approaches the vehicle.	ON	ON/OFF
Light Control	Response Time*3	To change the delay timing of lighting the taillight when going into the tunnel in case that the light control switch is at AUTO position.	Normal	Long/ Normal
	Sensitivity	To adjust the sensitivity of the lighting illumination.	Normal	Dark 2 / Dark 1 / Normal / Light 1 / Light 2
	Disp Ex ON Sen	To change the brightness of canceling the lowering the lights such as the indicator light of the combination meter, A/C indicator light, clock.	Normal	Dark 2 / Dark 1 / Normal / Light 1 Light 2
	Disp EX OFF Sen	To change the brightness of lowering the lights such as the indicator light of the combination meter, A/C indicator light, clock.	Normal	Dark 2 / Dark 1 / Normal / Light 1 / Light 2
Entry and Start	Ignition Available Area	Setting an available area of SMART ignition	ALL	ALL/ FRONT
	Park Wait Time	Setting a wait time to permit opening a door after it being locked.	2.5 s	0.5 s / 1.5 s / 2.5 s / 5 s
	Trunk Open Mode	Function to permit opening a trunk with the key.	ON	ON/OFF
	Key Low Battery Warning	Function to set a warning function for the time when a key battery becomes weak.	ON	ON/OFF

(Continued)

System	Display Content	Contents	Default Setting	Available Setting
Sliding Roof	Wireless Key Related Operation	Function to select the opening direction of the manual opening of the sliding roof linking with the power window if pressing on the transmitter unlock button for 1.5 seconds or more when the power source is OFF.	Slide	Tilt/Slide
	Door Key Related Operation	Function to select the opening direction of the manual opening of the sliding roof linking with the power window if holding the driver side door key for 1.5 seconds or more to the unlock side when the power source is OFF.	Slide	Tilt / Slide
	Door Handle Lock Button	Function to close sliding roof manually linking with power window if pushing door lock switch for 3 seconds or more when power source is OFF and key is outside vehicle.	ON	ON /OFF
	Wireless Key Related Close	Function to close the sliding roof manually linking with the power window if pressing on the transmitter lock button for 2.4 seconds or more when the power source is OFF.	ON	ON / OFF
	Wireless Key Related Open	Function to open the sliding roof manually linking with the power window if pressing on the transmitter unlock button for 2.4 seconds or more when the power source is OFF.	ON	ON / OFF
	Door Key Related Close	Function to close the sliding roof manually linking with the power window if holding the driver side door key for 1.5 seconds or more to the lock side when the power source is OFF.	ON	ON / OFF
	Door Key Related Open	Function to open the sliding roof manually linking with the power window if holding the driver side door key for 1.5 seconds or more to the unlock side when the power source is OFF.	ON	ON / OFF
Theft Deterrent	Warning by Horn*4	Function to make the warning by the horn and theft deterrent horn available.	ON	ON / OFF
Tilt and Telescopic	Autoaway / Return function	ON / OFF of the auto away / return function.	ON	ON / OFF
Meter	Units By Region	Function to change the unit of the display.	MI/g US	Km/l JP/Km/l / MI/g US /MI/g UK
	Driver Side Seatbelt Warning Buzzer	To change the seatbelt warning buzzer.	ON	ON/OFF
	Front Passenger Side Seatbelt Warning Buzzer	To change the seatbelt warning buzzer.	ON	ON/OFF
	Language*5	Function to change the language of the display.	English/ French/ German/ Spanish/ Italian/ Chinese	English/ French/ German/ Spanish/ Italian/ Chinese

(Continued)

System	Display Content	Contents	Default Setting	Available Setting
Clearance Sonar* ⁶	Fr Sensor Onset Range	Function to set a range which front buzzer starts to beep.	Wide	Narrow / Wide
	Rr Sensor Onset Range	Function to set a range which rear buzzer starts to beep.	Wide	Narrow / Wide
	Keep Sense Buzzer	Function to make buzzer sound when distance between vehicle and obstacle does not change for more than 3 seconds.	Avail	Not Avail / Avail
	Fr & Rr Buzzer Freq	Function to change frequency of front and rear buzzer.	Middle	Low / Middle / High
	Fr & Rr Buzzer Volume	Function to change volume of front and rear buzzer.	M3	L/ M1/ M2/ M3/ H
	Sensor Condition N	Function to make sensors available when shift position is N.	Avail	Not Avail / Avail
	Front Side Dist Sensor	Function to change maximum distance that front side sensors are able to detect.	Long	Short/ Long
	Approach Display OFF	Function to make multi-information display turn off when vehicle starts to leave obstacle.	Avail	Not Avail / Avail
	Non P/R Range Rear Sensor	Function to set available sensors when shift position is not P or R.	R Stop	R / Rcrn / R Stop

*1: Only OFF is set for the default setting and available settings on Chinese models

*2: Only for VX grade

*3: Except European models

*4: Models with security horn except European models

*5: Languages used on the display differ depending on destinations

*6: Optional Equipment