

CLEARANCE SONAR SYSTEM

■ DESCRIPTION

- The clearance sonar system is optional equipment.
- The clearance sonar system uses ultrasonic sensors to detect any obstacles at the corners, or the rear of the vehicle.
- The clearance sonar system then informs the driver of the approximate distance between the sensors and the obstacles as well as their positions by displaying them on the multi-information display in the combination meter or the multi-display* and by sounding a clearance warning buzzer.
- The clearance sonar system is controlled by the clearance warning ECU.
- The operating condition of each clearance sonar system differs according to its installed position as shown in the table below:

Installation Position	Operating Condition
Ultrasonic Sensor (Front Corner LH and RH)	• Power source is IG-ON. • Shift position is in any position other than P. • Vehicle speed is approximately 10km/h (6 mph) or less. The sensor stops operating when the vehicle speed is 13 km/h (8mph) or more, and starts operating when the vehicle speed decreases to below 9km/h (5.6 mph).
Ultrasonic Sensor (Rear Corner LH and RH) Ultrasonic Sensor (Rear Center LH and RH)	• Power source is IG-ON • Shift position is R. • Back sonar or clearance sonar switch is ON.

*: Optional Equipment