

■ CENTER AIRBAG SENSOR ASSEMBLY

- When the airbag system reaches a decision to deploy the airbags based on the signals detected by the front airbag sensors and the center airbag sensor assembly, it deploys the driver and front passenger dual-stage SRS airbags, driver knee airbag, front passenger knee airbag, and seat belt pretensioners. When the airbag system reaches a decision to deploy the airbags based on the signals detected by the side airbag sensors, rear airbag sensors, rear floor side airbag sensor, and center airbag sensor assembly, it deploys the SRS front side airbags, rear side airbags, and SRS curtain shield airbags. Furthermore, it is equipped with a diagnosis function to perform self-diagnose system malfunctions.
- The center airbag sensor assembly has 4 built-in sensors: Deceleration sensor 1 detects vehicle deceleration in the lateral direction in addition to the longitudinal direction, deceleration sensor 2 detects deceleration in the longitudinal direction, and the 2 roll rate sensors detect angular velocity in the roll direction.
- Each signal is transmitted as follows:

Target ECU	Signal	Communication Path
ECM	Collision Detection Signal	CAN Communication Circuit
Combination Meter Assembly	• Driver Front Seat Buckle Switch ON Demand Signal • SRS Warning Light ON Demand Signal	CAN Communication Circuit

*: Provided on models with SRS curtain shield airbags

■ DIAGNOSIS

- If the center airbag sensor assembly detects a malfunction in the SRS airbag system, the center airbag sensor assembly stores the malfunction data in memory, in addition to illuminating the SRS warning light.
 - There are 2 types of DTC for the SRS airbag system: 5-digit and 2-digit.
 - The 5-digit DTC can be read by connecting an intelligent tester II to DLC3.
 - The 2-digit DTC can be read by connecting the SST (09843-18040) to the TC and CG terminals of the DLC3 and reading the blinking of the SRS warning light.
 - If the SRS airbags deploy, the center airbag sensor assembly will turn ON the SRS warning light. If the SRS airbags deploy, the center airbag sensor assembly will turn ON the SRS warning light and stores a DTC. The SRS warning light can be turned OFF only by replacing the center airbag sensor assembly with a new one.