

6. PROCEDURES NECESSARY WHEN ECU OR OTHER PARTS ARE REPLACED

(a) THE WORK LIST

(1) Each inspection procedure refers to the TOYOTA Repair Manual.

Replacement Part	Necessary Procedures	Effects/Inoperative Functions When Necessary Procedures are not Performed	Notes
ECM	Register VIN.	DTC P0630 is output.	—
Automatic transmission assembly	Reset memory.	Large shift shock.	—
Valve body assembly	Reset memory.	Large shift shock.	—
Any of shift solenoid valves	Reset memory.	Large shift shock.	—
Tire pressure warning ECU	- Register transmitter IDs. - Initialize tire pressure warning system.	- When DTC detection conditions of "transmitter ID not received" DTC is met, tire pressure warning light blinks for 1 minute, and then illuminates. - Tire pressure monitoring function	—
Tire pressure warning valve and transmitter	- Register transmitter IDs - Initialize tire pressure warning system	- When DTC detection conditions of "transmitter ID not received" DTC is met, tire pressure warning light blinks for 1 minute, and then illuminates - Tire pressure monitoring function of replaced wheel	Even if only one wheel is replaced, IDs for all 5 wheels must be registered
Master cylinder solenoid (Skid control ECU)	Yaw rate and G sensor zero point calibration.	- ABS warning light illumination "Check VSC System" indication on the multi-information display	—
Yaw rate and a sensor	- Clearing zero point calibration data. - Yaw rate and G sensor zero point calibration.	- ABS warning light illumination "Check VSC System" indication on the multi-information display	—
Garage door opener transmitter	Registration	Garage door does not operative	—
- ID code box - Steering lock ECU - ECM - Key - Certification ECU	Registration	- Wireless door lock operation - Entry operation - Engine starting - Steering unlock	—
No. 1 seat cushion assembly (occupant classification ECU and occupant detection sensor)	- Zero point calibration - Registration - Sensitivity check	- Occupant classification system - Passenger airbag ON/OFF indicator - Airbag system (Front passenger side) - Seat belt warning system (Front passenger side)	—
- Front Power window regulator motor LH - Front Power window regulator motor RH - Rear Power window regulator motor LH - Rear Power window regulator motor RH	Initialize the motor	- Jam protection function. - Power window control system	—
- Sliding roof driver gear (Sliding roof ECU) - Sliding roof glass	Initialize sliding roof system	- Auto operation. - Jam protection function. - Sliding roof operation after engine switch OFF. - Wireless door lock control function. - Key-linked operation function (Driver side door only). - Entry lock switch-linked operation.	—