

■ FUNCTION OF MAIN COMPONENTS

Component		Function
Ultrasonic Sensors		Detects the distance between the vehicle and the obstacle.
Clearance Warning Buzzer		Sounds a buzzer to inform the driver according to the distance to the obstacle.
Combination Meter		Transmits the vehicle speed signal to the clearance warning ECU.
	Multi-information Display	- Displays the location of the obstacle and the approximate distance between the vehicle and the obstacle. - Informs the driver if the ultrasonic sensors malfunction, or if they freeze or become dirty.
	Master Warning Light	Illuminates when the multi-information display indicates that the ultrasonic sensors are malfunctioning or frozen.
Multi-display*		- Displays the location of the obstacle and the approximate distance between the vehicle and the obstacle. - The sound volume, distance required to sound the buzzer and distance required to trigger the display can be chosen on the setup screen for the clearance sonar system.
Clearance Warning ECU		Judges the approximate distance between the vehicle and an obstacle based on signals from the ultrasonic sensors. Output signals are sent to the multi-information display and/or multi-display.
ECM		Transmits the shift position signal to the clearance warning ECU.
Air Conditioning Amplifier Assembly		Transmits the outside temperature to the clearance warning ECU.
Windshield Wiper ECU*		Transmits the wiper status signal to the main body ECU.
Main Body ECU		Transmits the wiper status signal and dimmer signal to the clearance warning ECU.
Clearance Sonar Main Switch		Operating this switch allows the operation of clearance sonar system to be enabled or disabled.

*: Optional Equipment