

ENTRY AND START SYSTEM

■ DESCRIPTION

The entry and start system not only has a wireless door lock remote control function and engine immobiliser function, but simply by carrying the key, the following functions (entry function and push button start function) are also possible without having to actually use the key or transmitter button. It is an extremely convenient system.

- Door unlock/lock (Entry Unlock/Entry Lock Functions)
- The engine can be started simply by pushing the engine switch while depressing the brake pedal*¹ or clutch pedal*² (Start Function)
- The back door can be opened (Back Door Open Function)
- Wireless door lock control function.

This system is standard equipment.

*1: Models with automatic transmission

*2: Models with manual transmission

Entry Lock/Unlock Functions



Start Function



Back Door Open Function