

MEMORY SYSTEM

■ DESCRIPTION

- The memory system is standard equipment on Chinese VX grade models and optional equipment on European models.
- The memory system can store 3 positions for the driver seat, outer rear view mirror assembly, and steering column assembly respectively.
- The driver seat ECU stores seat slide, front vertical, rear vertical, and reclining positions in its memory.
- The outer mirror control ECU stores the outer rear view mirror position in its memory.
- The multiplex tilt & telescopic ECU stores the tilt and telescopic position in its memory.
- The driver seat ECU outputs a signal to each ECU to reproduce the stored settings.
- A memory call function, which utilizes the key IDs of the transmitter, is used to memorize and retrieve the optimal driving positions for a person possessing the key. (For details, see page BE-181.)
- The memory and recall conditions of this system are as follows.

Function	Condition
Memory	Stores the positions when both conditions below have been met and switch 1, 2, or 3 is pushed while the SET switch is pushed. • Engine switch is on (IG). • Shift position is P. When the memory setting is completed, the buzzer will sound for approximately 0.5 seconds.
Recall	If switch 1, 2, or 3 is pressed when both conditions below have been met, the system operates to adjust the positions. • Engine switch is on (IG). • Shift position is P. If switch 1, 2, or 3 is pressed when both conditions below have been met and within 30 seconds, the system operates to adjust the positions. • Engine switch is off. • Driver door is opened. The buzzer sounds for approximately 0.1 seconds once the stored seat position is reproduced.

► System Diagram ◀

