



## Parent and Rider Manual

# STOP!

### DO NOT RETURN TO STORE

This product cannot be returned for a refund after it has been unpacked and used.

Call us Toll-Free  
at 1-866-424-0500 or Fax  
us at 1-775-248-5155 for  
assistance and information  
from our  
trained technical staff.

### **CAUTION: THIS IS AN ELECTRONICALLY OPERATED PRODUCT.**

The charger is an electronically operated product – not a part of the toy.

Not recommended for children under 3 years of age.

As with all electronic products, precautions should be observed  
during handling and use to prevent electric shock.

For assistance with your assembly call:  
**1.866.424.0500** toll-free  
**417.206.0563** Local





Official Licensed Product

# 6V 3-Wheel Scooter Ride-On Toy

With directions for assembly and operation

## Parent and Rider Manual

Suitable for 3-5 years

Please read this manual before assembly.  
Remember to save your receipt.

*Metropolitan*



### WARNING:

Assembly by an adult.



### WARNING:

CHOKING HAZARD- Small parts.  
Not for children under 36 months.

**easy1·2·3**  
**ASSEMBLY**

(All required tools included!)  
It is recommended that riders  
always wear a helmet.

DISTRIBUTED BY:  
Ballard Pacific Resources Inc.  
1-866-424-0500 toll-free  
or 417-206-0563 Local  
410 Adele Joplin, Mo. 64801

Ballard Pacific

**ACTION WHEELS**



# Table of Contents

<b>Important Information .....</b>	<b>1</b>
<b>Safety, Warnings and Cautions .....</b>	<b>2</b>
<b>Riding Safety.....</b>	<b>3</b>
<b>Battery Charging and Installation.....</b>	<b>4</b>
<b>Parts Diagram .....</b>	<b>5</b>
<b>Step-by-Step Assembly.....</b>	<b>6-10</b>
<b>Toy Care .....</b>	<b>11</b>
<b>Solutions Guide.....</b>	<b>12</b>
<b>Limited Warranty .....</b>	<b>13</b>
<b>Product Registration.....</b>	<b>14</b>

**Notes:**

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

---

## Important Information

### ● ADULT ASSEMBLY REQUIRED.

- The battery must be charged for 14 hours before the toy's first use. To start charging the battery before starting assembly, see Battery Charging and Installation information on Page 4.
- Instruct children on safe operation and driving rules before they take their first ride:
  - only one rider at a time
  - always wear shoes when riding the toy
  - always wear your helmet.
  - do not allow other children near the toy when riding
  - do not place your hands, feet, or any part of your body, clothing, or other articles near moving parts while the toy is in operation
  - do not sit on the rear end of seat, it could cause tip over. Sit on the middle of seat when riding.
- Do not overload the toy or exceed the maximum weight capacity of 44 lbs. (20kg).  
If you have questions please call 1-866-424-0500
- Never operate toy without adult supervision.
- **Please read this manual completely** for operation and safety information **before** using the toy. Keep these instructions for future reference.

For assistance with your assembly call:  
**1.866.424.0500** toll-free  
**417.206.0563** Local

# Safety

# Warnings and Cautions

## ⚠ WARNING: Electrical Hazard

**RISK OF FIRE.** Do not bypass the fuse. Replace only with the same 15A fuse (on battery pack).

- Only use a Ballard Pacific Resources, Inc. 6V lead-acid battery.
- Only use a Ballard Pacific Resources, Inc. 6V charger.
- Never modify the electrical system. Changes could cause a fire resulting in serious injury or death, and could also ruin the electrical system.
- Never lift or carry the battery by the wires or connectors. This can damage the battery and possibly cause a fire resulting in serious injury or death. Always use the battery holder to carry it.
- The battery should be handled by adults only. The battery is heavy and contains sulfuric acid (electrolyte). Always use the attached battery handle for carrying.
- Children should never be allowed to charge the battery. Charging the battery must be done by adults only. The electricity involved in charging the battery could injure a child.
- The motors will get hot, handle carefully.
- Each time you charge the battery; check the battery, charger, and their connectors for excessive wear or damage. Do not use the charger or the battery if damage or excessive wear is detected until you have replaced the worn or damaged parts.
- Carefully read the safety instructions about the battery.

## ⚠ WARNING: Riding Hazard

To reduce the risk of injury, adult supervision is required

- Never use on roadways or near motor vehicles
- Never use on or near steep inclines or steps
- Never ride near swimming pools or other bodies of water
- Always wear shoes while riding
- Never allow more than 1 rider at one time
- Max weight of 44 lbs. (20kgs)

## ⚠ WARNING: Charger

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

**NOTE:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

## ⚠ CAUTION:

- When fully unassembled, this package contains small parts. Adult assembly is required.
- Use the charger in dry ventilated areas only.

For assistance with your assembly call:  
**1.866.424.0500** toll-free  
**417.206.0563** Local



# Safety

## Rules for Riding Safety

### ⚠ WARNING: Adult Supervision Required

- Always Teach Safety First.
- While most children can develop the physical skills necessary to operate this toy, it is important to remember that they do not yet have mature judgment skills. Children should never be allowed to ride this toy without adult supervision. Before any child rides this toy an adult must evaluate the child's skill levels and abilities to operate the toy safely. Even after instruction, hazards are not always anticipated or recognized by children. So before any child operates the vehicle teach them appropriate safety rules.
- THERE IS NO SUBSTITUTE FOR DIRECT ADULT SUPERVISION.

### ⚠ WARNING: Safe Riding Rules

- Always wear your helmet.
- Always wear shoes.
- Only one rider at a time.
- Do not operate on loose dirt, sand or gravel.
- Do not operate near drop-offs, bodies of water, or obstructions.
- Do not operate in the street or near moving vehicles.
- Do operate on inclines. Use on generally level ground only.
- Do not operate in the dark as unexpected obstacles could cause an accident.
- Do not operate on slopes.
- Do not place anything near moving parts such as motors, gears or wheels. Rotating parts can snag hair, fingers, etc. causing serious injury.
- Do not operate near flammable vapors (such as gasoline, paint thinner, acetone, liquid wax, etc.).
- Do not sit on the rear end of seat – it could cause tip over. Sit on the middle of seat when riding.

For assistance with your assembly call:  
**1.866.424.0500** toll-free  
**417.206.0563** Local

# Battery

## Charging and Installation

**⚠ CAUTION: The battery and charger are not toys.  
All battery charging must be done by an adult.**

### The battery is located under the seat. Use the provided screwdriver to remove the seat.

- The battery must be charged 14 hours before its first use. The battery must be in the upright position before charging, and be very careful to avoid any contact to both terminals at the same time.
- To disconnect the battery, squeeze the tabs of the connector and pull. Hold the connectors firmly, and do not pull the wires.
- Connect the battery charging line with the charger connector, then plug the charger into the wall outlet.
- Make sure to only plug the charger into standard 120V wall outlets. Use only the charger supplied. The charger has the rating: Input AC 120V 60Hz, Output DC7.0V 0.8A.
- You must recharge the battery for 8-12 hours after each time you use the toy. Never charge for more than 16 hours after first charge.
- Disconnect the charger from the wall outlet and then the charger from the battery. If you are not going to use the toy for a long period of time, make sure you recharge the battery at least once a month.
- Never lift or carry the battery by the wires or connectors. This can damage the battery and possibly cause a fire resulting in serious injury or death. Always use the battery handle to carry it.
- Do not charge or store the battery upside down. Charging the battery produces explosive gasses. Make sure to charge the battery away from flames, sparks, and lit cigarettes. Always charge in a well ventilating area.

### CARE:

- Always charge the battery before storing the vehicle for a long period of time. Make sure to charge the battery at least once a month, even if the toy is not being used.
- Never let the battery run down completely before charging.
- Never leave the battery in a discharged condition. It may ruin it.
- Never store the battery in temperatures above 75 °F (28.8 °C) or below 10 °F (12.2 °C).
- Before each charge, examine the battery, charger, and their connectors for excessive wear or damage. If you find damage, do not use the battery or charger until you have replaced the worn or damaged part.
- Make sure to return exhausted batteries to an approved lead-acid battery recycler or contact your local authority accordingly.


### DISPOSAL:

- Your toy's battery is a sealed lead-acid battery. You must recycle or dispose of it in an environmentally sound manner.
- Never dispose your battery in the regular, household trash. The incineration, land-filling, or mixing of a sealed lead-acid battery with your household trash is prohibited by law in most areas.
- Make sure to return exhausted batteries to an approved lead-acid battery recycler or contact your local authority. Always remove exhausted batteries from your toy. Dispose of dead batteries properly; never burn or bury them.
- To locate a service center, contact your local waste management company.
- Do not mix old and new batteries.
- Do not mix alkaline, standard (carbon-zinc), or rechargeable (Nickel-Cadmium) batteries.

For assistance with your assembly call:  
**1.866.424.0500** toll-free  
**417.206.0563** Local

# Parts

# Parts Diagram



26	rear fairing
25	exhausting pipe assembly
24	body(R)
23	rear wheel
22	wheel hub
21	small rounded cover
20	foot pedal
19	front wheel
18	washer on front wheel
17	front axle
16	front fork
15	front fender
14	body bottom cover
13	pedal assembly
12	frame assembly
11	headset assembly
10	handle bar assembly
9	rear view mirror assembly
8	seat / seat back handle
7	battery assembly
6	body(L)
5	rear light assembly
4	rear fender(L/R)
3	gearbox assembly
2	rear axle
1	motor cover

For assistance with your assembly call:  
**1.866.424.0500** toll-free  
**417.206.0563** Local

**ACTION**  
**WHEELS**

# Assembly

## INCLUDED PARTS

• Body	1PC	• Front Wheel	1SET
• Product Manual	1PC	• Small Wheel Cover	2PCS
• Charger	1PC	• Wrench Tool	1PC
• Handle Bar	1SET	• Left Fender	1PC
• Rear Axle	1PC	• Right Fender	1PC
• Rear Wheel	2PCS	• Front Axle	1PC
• Rear Mirror(L&R)	2PCS		


## SPECIFICATION

Battery	6V5AH
Motor	6V 20W
Charger	Input AC120V 60Hz / Output DC7.0V 0.8A
Maxmium load	20KG(44LBS)
Work Time	Full recharge can use for 1-2h
Speed	2-3Km/h
Age	36 months - 60 months

For assistance with your assembly call:  
**1.866.424.0500** toll-free  
**417.206.0563** Local


# Assembly

## INSTALLMENT INSTRUCTION




### Install rear axle

Remove the tape holding the gearbox and rotate it into position for the axle to pass through. Remove the nuts, washers, and the bushing from the axle. The axle end with the welded plate belongs on the opposite side from the gearbox. Slide the axle through the body of the toy making certain that the axle passes through the frame tube within the body. Be sure the welded plate is on the bottom of the axle and is pushed into the body all the way.



### Install rear wheels

Put the rear wheel on the axle, then replace the washer and nut onto the axle and tighten nut securely with the wrench provided. Then place the small round cover over the nut. Repeat the process with the other rear wheel.




### Install front wheel

Take out the front axle, and remove the nut and washer. First position the front fender under the front forks and snap the fender into place. Then align the axle hole on the front wheel with the axle holes on the front forks, making sure all three holes line up. Slide the front axle through the holes, add the washer, and tighten into place with the nut.

For assistance with your assembly call:  
**1.866.424.0500** toll-free  
**417.206.0563** Local


**ACTION WHEELS**

# Assembly




## Install Fenders

Find Left and Right Side Fender. Push the Left Fender into the hole on the left side of the body as shown in pic 4. The Fender is installed correctly when it snaps into place. repeat the process with the Right Fender.




## Install Side Mirrors

Find Left and Right Side Mirrors. Push the Left Side Mirror into the hole on the left side of the Handle Bar as shown in pic 5. The mirror is installed correctly when it snaps into place. Repeat on right side.



## Install Handle Bar

Slide Handle Bar onto Handle Bar Connector. The Handle Bar is installed correctly when it snaps into place.




## Disassemble and assemble the seat

Screw to the “open” position on the seat by using the screwdriver and the lift seat. When assembling the seat, first put the front snap and the limiter into the relevant slots, and match the seat and body. Finally, turn the screw to the lock seat.

For assistance with your assembly call:  
**1.866.424.0500** toll-free  
**417.206.0563** Local


# Assembly



## Install Battery Connector


Connect the battery cable (black) to the system cable (white) making sure they are firmly seated together.

## OPERATION INSTRUCTIONS



## Foot Pedal Operation

When the child is ready to ride the unit, please make sure he or she is seated at all times. For forward or backward movement, place the Gear Switch to "Forward" or "Backward" and push down on the Foot Pedal. To stop, remove pressure from Foot Pedal. When the child is done using the unit, always place the Gear Switch to "Stop."




## Battery Recharge

To recharge the battery, you must first remove the seat. Disconnect the Battery Connector from the Cable Line Connector and plug the Battery Connector into the Charger Connector. Plug the AC Adaptor into the wall and the red light on the AC Adaptor should come on, showing the battery is charging. Stop recharging after 8-12 hours. After recharging, reconnect the Battery Connector to the Cable Line Connector and reconnect the seat.

For assistance with your assembly call:  
**1.866.424.0500** toll-free  
**417.206.0563** Local


**ACTION WHEELS**

# Assembly



## Change Battery

Disconnect battery connections first. Loosen the black strap on battery and take out the battery. Place new battery inside and re-connect battery connections.



## Change fuse

To change the fuse, disconnect the battery connectors. Remove the fuse stop piece on battery with screwdriver. Take off the fuse cover. Remove the bad or damaged fuse and replace with provided identical fuse. Finally, close the fuse cover and install the stop piece as shown in Pic 12 .

For assistance with your assembly call:  
**1.866.424.0500** toll-free  
**417.206.0563** Local

# Maintenance

## Toy Care

Check all screws, cap nuts and protective coverings regularly and tighten as required. Check plastic parts on a regular basis for cracks or broken pieces.

This product should be checked by an adult before use and be used only under constant adult supervision.

During snow or rainy weather, the toy should be stored inside or under a protective cover. Remember to charge the battery at least once per month while your toy is not in regular use.



Avoid operating the toy in wet or snowy conditions and do not spray the toy with a hose. Do not wash the toy with soap and water. Water or moisture in the motors or electrical switches can cause them to corrode and could cause switch or motor failure.



Avoid operating the toy on sand, loose dirt or gravel. Sand, loose dirt or gravel in the motors or electrical switches can cause them to jam and could cause switch or motor failure.



The toy can be wiped down with a soft, dry cloth. For a shiny finish, you can wipe plastic parts with a non-wax furniture polish applied to a soft-cloth. Do not use automotive wax. Do not use soap and water or spray the toy with a hose.



For assistance with your assembly call:  
**1.866.424.0500** toll-free  
**417.206.0563** Local

# Troubleshooting

# Solutions Guide

## Problem

**SHORT OPERATING TIME**  
**(Less than 45 minutes to 1 hour)**

## Possible Cause

Circuit breaker tripped

## Solution

Circuit breaker may trip and stop the toy if it is overloaded or if the driving conditions are too severe. The breaker will automatically reset after approximately 25 seconds, and the toy will operate normally. To avoid repeated shut downs, don't overload the toy by exceeding the weight limit 44 lbs. (20 kg), or by towing anything behind the toy. Don't drive up steep hills or run into objects, which can cause the wheels to stop turning while power is still being supplied to the motor. If breaker continually trips, contact Ballard Pacific Resources, Inc. at 1-866-424-0500.

## Toy is sluggish

Undercharged battery

A new battery must be charged for at least 14 hours before using the toy for the first time. After that, it must be recharged for at least 14 hours after each use. Never charge longer than 24 hours. Check all connectors, and make sure the charger connector is plugged into the battery. Also check that the charger is plugged into the wall. Make sure the power flow to the wall outlet is on.

Battery needs charging

Charge the battery for at least 14 hours after each use.

Old Battery will not accept a full charge

Rechargeable batteries don't last forever, even with proper care. Depending on toy use and use conditions, the average battery last 1 to 3 years. Contact Customer Service for Replacement Battery and Receive Free Shipping with Purchase of Battery. Never use substitute parts.

Toy is overloaded

Allow no more than 1 rider at a time, follow the 44lbs. (20 kg) weight capacity, and don't tow anything behind the toy.

Driving conditions are too extreme

Use only on a generally level ground.

## Only one rear wheel turns

Toy is operating in low speed

One rear wheel may spin when both rear wheels are raised off the ground while the toy is in low speed, which is not necessarily a problem. Check the drive system by raising the rear wheels off the ground and pressing the accelerator. If only one wheel spins, carefully put your hand on the spinning wheel to slow it down. The other wheel should begin to spin. If it doesn't spin, there may be a problem. Contact Ballard Pacific Resources, Inc. at 1-866-424-0500 for diagnosis and repair.

## Intermittent toy operation

Loose wire or connectors  
Motor or electrical switch damage

Check all wires and connectors to make sure they are tight. Contact Ballard Pacific Resources, Inc. at 1-866-424-0500 for diagnosis and repair.

## When the accelerator is pressed, the toy won't run without a push

Loose wire or connectors  
Dead spot on motor

Check all wires and connectors to make sure they are tight. Ballard Pacific Resources, Inc. at 1-866-424-0500 for diagnosis and repair.

## Motor-gearbox makes a loud grinding or clacking noise

Broken gears

Contact Ballard Pacific Resources, Inc. at 1-866-424-0500 for diagnosis and repair.

## Charger gets warm during use

This is normal and should not be a concern.

No action required. If the charger does not get warm during use, it does not mean it isn't working properly.

## Battery makes gurgling or sizzling noise while charging.

Some noise and swelling is normal and should not be a concern.

No action required. If the battery does not make noise while charging, it does not mean it isn't accepting the charge.

For assistance with your assembly call:  
**1.866.424.0500** toll-free  
**417.206.0563** Local



# Limited Warranty

**DON'T RETURN YOUR  
TOY TO THE STORE.**

## **Do not take back to store, call customer service with any problems or questions.**

Ballard Pacific Resources, Inc. offers the following limitations, terms and conditions to the original owner of the Ballard Pacific Resources, Inc. Electric Ride-On Toy. Should this Ballard Pacific Resources, Inc. Electric Ride-On Toy or any part determined defective by Ballard Pacific Resources, Inc. to be covered by this Limited Warranty, it will be repaired or replaced at Ballard Pacific Resources, Inc. sole option, which will be conclusive and binding. Under no circumstances does this limited warranty include the cost of travel or shipment to and from any retailer or consumer. Such cost, if any, shall be borne by the original or subsequent owner.

The Ballard Pacific Resources, Inc. Electric Ride-On Toy has not been designed or engineered for ramp riding, jumping, aggressive riding, in severe climates or over severe terrain, riding with heavy loads (over 44 lb. or 20kg) or any other similar activities. Such uses may damage the Ballard Pacific Resources, Inc. Electric Ride-On Toy, that can cause serious injury to the rider, and in all cases will void this warranty.

### **6 Months from the date of purchase on vehicle**

Ballard Pacific Resources, Inc. Electric Ride-On display, throttle and throttle assembly, control wiring harness, wiring and wiring harness, motor and associated transmission and all components not directly associated with the 6V battery are warranted 6 months from date of purchase to the ORIGINAL PURCHASER against any defects in material, manufacturing, and/or workmanship. If there is any evidence of consumer repair, the warranty is voided. Any claim of damage under this clause cannot be due to owner abuse or neglect and must first be reported to Ballard Pacific Resources, Inc. Customer Service and a Return Merchandise Authorization (RMA) tag to be issued.

### **3 Months from te date of the purchase on battery**

The battery must be charged for a full 18 hours before the units first use. The 6V battery and battery charger (AC Adaptor) that is included with the original toy is warranted to be free from defects in material, parts and/or workmanship, again not due to owner abuse or neglect. If there is evidence of customer repair or use of other's battery or charger, the warranty is voided. This limited warranty is only valid to the original purchaser and must first be reported to Ballard Pacific Resources, Inc. Customer Service and a Return Merchandise Authorization (RMA) tag be issued.

Wheels are considered a wear and tear item and are only under warranty in the event of manufacturer defect.

Items not covered under warranty terms under any conditions:

1. Damage due to failure to maintain the battery as accurately described on various product warning stickers and the products owner's manual.
2. Damage due to maintenance or the actual damage caused by the lack of maintenance.
3. Damage due to improperly assembled products.
4. Damage due to climatic or environmental damage, various cleaners and/or chemicals that may result in a damaged finish.

This warrantly does not cover and is intended to exclude, any liability on the part of Ballard Pacific Resourcess, Inc. whether under this warranty or implied by law or indirect or consequential damages for breach of warranty.

This warranty gives you specific legal rights. You may also have other rights that vary from state to state and province to province. In those states that do not allow the exclusion of implied warranties or limitation of incidental or consequential damages, the above limitations or exclusions may not apply to you. This warranty applies to the United States and Canada.

**DON'T RETURN YOUR VEHICLE TO THE STORE.** Should you require service or assistance with your toy during the warranty period, contact our trained technical staff at Ballard Pacific Resources, Inc. 1-866-424-0500.

**For assistance with your assembly call:**  
**1.866.424.0500** toll-free  
**417.206.0563** Local



# Product Registration

## Note:

Activation of your warranty gives you FREE telephone and online technical service help. Please fill out registration below and immediately mail with your sales receipt to:

410 S. Adele Ave.  
Joplin, MO 64801



**!** For a record of your purchase fill in  
immediately and send to:  
410 S. Adele Ave. Joplin, Mo. 64801

Ballard Pacific  
Resources, Inc.



Designed, manufactured and distributed by **Ballard Pacific Resources**. Honda®, the Wing® logo, Honda vehicle model name Metropolitan and their trade dress are trademarks of Honda Motor Co., Ltd. used under license from American Honda Motor Co., Inc. Many Honda vehicle model names and trade dress may be seen at [www.honda.com](http://www.honda.com). All rights reserved.

HONDA

*Metropolitan*

Owners Name: \_\_\_\_\_  
(PLEASE PRINT)

Address: \_\_\_\_\_  
(PLEASE PRINT)

City: \_\_\_\_\_ State: \_\_\_\_\_ Zip: \_\_\_\_\_

Tel: \_\_\_\_\_ E-mail: \_\_\_\_\_

Date Purchased: \_\_\_\_\_ Place of Purchase: \_\_\_\_\_

Model Name: \_\_\_\_\_

Serial Number: \_\_\_\_\_

For assistance with your assembly call:  
**1.866.424.0500** toll-free  
**417.206.0563** Local

