# **OPERATION OF** VEHICLE CONTROLS

### METERS AND WARNING INDICATORS



- (a) Speedometer
- (b) Trip Odometer
- (c) Odometer
- (d) Signal Indicators
- (e) Tachometer or Rev Counter
- (f) Fuel Gauge

- (g) Temperature Gauge
- (h) High Beam Indicator
- (i) Door Warning Light
- (j) Brake Warning Light
- (k) Oil Pressure Warning Light
- (l) Battery Warning Light

## Speedometer

55 Indicates the speed at which you are travelling.

#### Odometer

56 Records the mileage travelled.

### **Trip Odometer**

57 This meter can be reset to record mileage travelled per trip.

