Public Service, Heavy Goods and Agricultural Vehicles

IM I	No. *	Component	IM N	o. *	Component
#	3	Seat Belts	#	33	Speed Limiters
#	5	Exhaust Emissions		34	Pressure / Vacuum Warning and Build Up
	6	Road Wheels and Hubs		36	Hand Lever Operating Mechanical Brakes
#	7	Size and Type of Tyres		37	Service Brake Pedal
#	8	Condition of Tyres		38	Service Brake Operation
	9	Sideguards, Rear Under-Run Devices and Bumper Bars		39	Hand Operated Brake Control Valve
	10	Spare Wheel and Carrier		41	Condition of Chassis
	11	Vehicle to Trailer Coupling		42	Electrical Wiring and Equipment
#	12	Trailer Parking and Emergency Brakes and Air Line Connections		43	Engine and Transmission
	13	Trailer Landing Legs		44	Oil and Waste Leaks
#	14	Spray Suppression, Wings and Wheel Arches		45	Fuel Tanks and Systems
	15	Cab Security		46	Exhaust Systems and PSV Waste Systems
	16	Driver and Passenger Doors	#	48	Suspension
#	17	Driver's Accommodation and Steps		53	Axles, Stub Axles and Wheel Bearings
	18	Driver's Seat		54	Steering Mechanism
	19	Security of Body		57	Transmission
	20	Condition of Body		58	Additional Braking Devices (including retarders)
	21	Interior of Body		59	Brake Systems and Components
#	22	Driver's Mirrors	#	62	Rear Markings and Reflectors
#	23	Glass and View of the Road	#	63	Lamps
#	25	Windscreen Wipers and Washers	#	66	Direction Indicators and Hazard Warning Lamps
#	26	Speedometer / Tachograph	#	67	Aim of Headlamps
#	27	Audible Warning (Horn)	#	71	Service Brake Performance
	28	Driving Controls	#	72	Secondary Brake Performance
	30	Steering Control	#	73	Parking Brake Performance

^{*} IM = Inspection Manual for HGV and PSVs

= For agricultural vehicles see below

An agricultural motor vehicle, trailer or trailed appliance is one that is constructed or adapted for use off roads for the purpose of agricultural, horticulture or forestry and which is primarily used for one or more of these purposes, but does not include a 'dual-purpose' vehicle as defined in the Road Vehicles (Construction and Use) Regulations.

They fall into two distinct groups: those driven at speeds not exceeding 20mph and those driven / drawn at speeds in excess of 20mph.

For all types of agricultural vehicle IM references 3, 21 and 33 will not apply.

For types driven / drawn at speeds not in excess of 20mph the following IMs might not apply, or might apply in part only: IMs 5, 7, 8, 12, 14, 17, 22, 23, 25, 26, 27, 48, 62 to 67 inclusive and 71 to 73 inclusive.

As a general rule when inspecting these slower vehicles and using the IMs mentioned above, examiners should only be concerned with items that they find fitted. That is, a vehicle should not be considered defective if a particular item was not fitted as original equipment.