

AI-ROBO Hardware Installation Guide

Thank you for choosing AI-ROBO. This guide ensures a safe setup.

Section 1: Safety Precautions

- Read all instructions carefully before starting.
- Do not operate in wet or hazardous environments.
- Always wear protective gear during the installation.
- Keep hands away from robot joints during power-up.

Section 2: Installation Requirements

- Power: 200-240V AC, 50/60Hz single phase.
- Temperature: 0 to 45 degrees Celsius.
- Mounting: Steel base with at least 15mm thickness.

Section 3: Physical Setup

1. Secure the base to the mounting surface using provided bolts.
2. Connect the robot arm to the control box using the primary cable.
3. Ensure all connectors are locked and secured.
4. Mount the end-effector (tool) to the robot flange.

Section 4: Control Box Configuration

- Connect the teach pendant to the dedicated port.
- Switch on the main power on the back of the control box.
- Follow the on-screen calibration steps on the pendant.

For technical support, visit: www.ai-robo-support.com

Contact: support@ai-robo.com | +82 2-1234-5678